

Rexroth IndraDyn S MSK Synchronous Motors

R911325169
Edition 02

Instructions



Title	Rexroth IndraDyn S MSK Synchronous Motors									
Type of Documentation	Instructions									
Document Typecode	DOK-MOTOR*-MSK*****-IT02-EN-P									
Internal File Reference	RS-f09c4486099dde6f0a6846a000c1508d-3-en-US-7									
Purpose of Documentation	This documentation ... <ul style="list-style-type: none">• briefs mounting, operating and maintenance personnel,• contains basic instructions on the assembly, operation and maintenance of the motors.									
Record of Revision	<table border="1"><thead><tr><th>Edition</th><th>Release Date</th><th>Notes</th></tr></thead><tbody><tr><td>DOK-MOTOR*-MSK*****-IT01-EN-P</td><td>06/2011</td><td>First edition</td></tr><tr><td>DOK-MOTOR*-MSK*****-IT02-EN-P</td><td>12/2012</td><td>First edition</td></tr></tbody></table>	Edition	Release Date	Notes	DOK-MOTOR*-MSK*****-IT01-EN-P	06/2011	First edition	DOK-MOTOR*-MSK*****-IT02-EN-P	12/2012	First edition
Edition	Release Date	Notes								
DOK-MOTOR*-MSK*****-IT01-EN-P	06/2011	First edition								
DOK-MOTOR*-MSK*****-IT02-EN-P	12/2012	First edition								
Copyright	© Bosch Rexroth AG 2011 Copying this document, giving it to others and the use or communication of the contents thereof without express authority, are forbidden. Offenders are liable for the payment of damages. All rights are reserved in the event of the grant of a patent or the registration of a utility model or design (DIN 34-1).									
Validity	The specified data is for product description purposes only and may not be deemed to be guaranteed unless expressly confirmed in the contract. All rights are reserved with respect to the content of this documentation and the availability of the product.									
Published by	Bosch Rexroth AG Bgm.-Dr.-Nebel-Str. 2 ■ 97816 Lohr a. Main, Germany Phone +49 (0)93 52/ 18-0 ■ Fax +49 (0)93 52/ 18-84 00 http://www.boschrexroth.com/electrics Dept. DC-IA/EDM3 (jw/mb)									
Note	This document has been printed on chlorine-free bleached paper.									

D Deutsch	USA English	F Français
<p>⚠WARNING Lebensgefahr bei Nichtbeachtung der nachstehenden Sicherheitshinweise!</p> <p>Nehmen Sie die Produkte erst dann in Betrieb, nachdem Sie die mit dem Produkt gelieferten Unterlagen und Sicherheitshinweise vollständig durchgelesen, verstanden und beachtet haben.</p> <p>Sollten Ihnen keine Unterlagen in Ihrer Landessprache vorliegen, wenden Sie sich an Ihren zuständigen Rexroth-Vertriebspartner.</p> <p>Nur qualifiziertes Personal darf an Antriebskomponenten arbeiten.</p> <p>Nähere Erläuterungen zu den Sicherheitshinweisen entnehmen Sie Kapitel 1 dieser Dokumentation.</p>	<p>⚠WARNING Danger to life in case of non-compliance with the below-mentioned safety instructions!</p> <p>Do not attempt to install or put these products into operation until you have completely read, understood and observed the documents supplied with the product.</p> <p>If no documents in your language were supplied, please consult your Rexroth sales partner.</p> <p>Only qualified persons may work with drive components.</p> <p>For detailed explanations on the safety instructions, see chapter 1 of this documentation.</p>	<p>⚠AVERTISSEMENT Danger de mort en cas de non-respect des consignes de sécurité figurant ci-après !</p> <p>Ne mettez les produits en service qu'après avoir lu complètement et après avoir compris et respecté les documents et les consignes de sécurité fournis avec le produit.</p> <p>Si vous ne disposez pas de la documentation dans votre langue, merci de consulter votre partenaire Rexroth.</p> <p>Seul un personnel qualifié est autorisé à travailler sur les composants d'entraînement.</p> <p>Vous trouverez des explications plus détaillées relatives aux consignes de sécurité au chapitre 1 de la présente documentation.</p>
<p>⚠WARNING Hohe elektrische Spannung! Lebensgefahr durch elektrischen Schlag!</p> <p>Betreiben Sie Antriebskomponenten nur mit fest installiertem Schutzleiter.</p> <p>Schalten Sie vor Zugriff auf Antriebskomponenten die Spannungsversorgung aus.</p> <p>Beachten Sie die Entladezeiten von Kondensatoren.</p>	<p>⚠WARNING High electrical voltage! Danger to life by electric shock!</p> <p>Only operate drive components with a permanently installed equipment grounding conductor.</p> <p>Disconnect the power supply before accessing drive components.</p> <p>Observe the discharge times of the capacitors.</p>	<p>⚠AVERTISSEMENT Tensions électriques élevées ! Danger de mort par électrocution !</p> <p>N'exploitez les composants d'entraînement que si un conducteur de protection est installé de manière permanente.</p> <p>Avant d'intervenir sur les composants d'entraînement, coupez toujours la tension d'alimentation.</p> <p>Tenez compte des délais de décharge de condensateurs.</p>
<p>⚠WARNING Gefahrbringende Bewegungen! Lebensgefahr!</p> <p>Halten Sie sich nicht im Bewegungsbereich von Maschinen und Maschinenteilen auf.</p> <p>Verhindern Sie den unbeabsichtigten Zutritt für Personen.</p> <p>Bringen Sie vor dem Zugriff oder Zutritt in den Gefahrenbereich die Antriebe sicher zum Stillstand.</p>	<p>⚠WARNING Dangerous movements! Danger to life!</p> <p>Keep free and clear of the ranges of motion of machines and moving machine parts.</p> <p>Prevent personnel from accidentally entering the range of motion of machines.</p> <p>Make sure that the drives are brought to safe standstill before accessing or entering the danger zone.</p>	<p>⚠AVERTISSEMENT Mouvements entraînant une situation dangereuse ! Danger de mort !</p> <p>Ne séjournez pas dans la zone de mouvement de machines et de composants de machines.</p> <p>Évitez tout accès accidentel de personnes.</p> <p>Avant toute intervention ou tout accès dans la zone de danger, assurez-vous de l'arrêt préalable de tous les entraînements.</p>
<p>⚠WARNING Elektromagnetische / magnetische Felder! Gesundheitsgefahr für Personen mit Herzschrittmachern, metallischen Implantaten oder Hörgeräten!</p> <p>Zutritt zu Bereichen, in denen Antriebskomponenten montiert und betrieben werden, ist für oben genannten Personen untersagt bzw. nur nach Rücksprache mit einem Arzt erlaubt.</p>	<p>⚠WARNING Electromagnetic / magnetic fields! Health hazard for persons with heart pacemakers, metal implants or hearing aids!</p> <p>The above-mentioned persons are not allowed to enter areas in which drive components are mounted and operated, or rather are only allowed to do this after they consulted a doctor.</p>	<p>⚠AVERTISSEMENT Champs électromagnétiques / magnétiques ! Risque pour la santé des porteurs de stimulateurs cardiaques, d'implants métalliques et d'appareils auditifs !</p> <p>L'accès aux zones où sont montés et exploités les composants d'entraînement est interdit aux personnes susmentionnées ou bien ne leur est autorisé qu'après consultation d'un médecin.</p>
<p>⚠VORSICHT Heiße Oberflächen (> 60 °C)! Verbrennungsgefahr!</p> <p>Vermeiden Sie das Berühren von metallischen Oberflächen (z. B. Kühlkörpern). Abkühlzeit der Antriebskomponenten einhalten (mind. 15 Minuten).</p>	<p>⚠CAUTION Hot surfaces (> 60 °C [140 °F])! Risk of burns!</p> <p>Do not touch metallic surfaces (e.g. heat sinks). Comply with the time required for the drive components to cool down (at least 15 minutes).</p>	<p>⚠ATTENTION Surfaces chaudes (> 60 °C)! Risque de brûlure !</p> <p>Évitez de toucher des surfaces métalliques (p. ex. dissipateurs thermiques). Respectez le délai de refroidissement des composants d'entraînement (au moins 15 minutes).</p>

D Deutsch	USA English	F Français
<p>A VORSICHT Unsachgemäße Handhabung bei Transport und Montage! Verletzungsgefahr!</p> <p>Verwenden Sie geeignete Montage- und Transporteinrichtungen.</p> <p>Benutzen Sie geeignete Werkzeug und persönliche Schutzausrüstung.</p>	<p>CAUTION Improper handling during transport and mounting! Risk of injury!</p> <p>Use suitable equipment for mounting and transport.</p> <p>Use suitable tools and personal protective equipment.</p>	<p>ATTENTION Manipulation incorrecte lors du transport et du montage ! Risque de blessure !</p> <p>Utilisez des dispositifs de montage et de transport adéquats.</p> <p>Utilisez des outils appropriés et votre équipement de protection personnel.</p>
<p>A VORSICHT Unsachgemäße Handhabung von Batterien! Verletzungsgefahr!</p> <p>Versuchen Sie nicht, leere Batterien zu reaktivieren oder aufzuladen (Explosions- und Verätzungsgefahr).</p> <p>Zerlegen oder beschädigen Sie keine Batterien. Werfen Sie Batterien nicht ins Feuer.</p>	<p>CAUTION Improper handling of batteries! Risk of injury!</p> <p>Do not attempt to reactivate or recharge low batteries (risk of explosion and chemical burns).</p> <p>Do not dismantle or damage batteries. Do not throw batteries into open flames.</p>	<p>ATTENTION Manipulation incorrecte de piles! Risque de blessure!</p> <p>N'essayez pas de réactiver des piles vides ou de les charger (risque d'explosion et de brûlure par acide).</p> <p>Ne désassembliez et n'endommagez pas les piles. Ne jetez pas des piles dans le feu.</p>

E Español	P Português	I Italiano
<p>ADVERTENCIA ¡Peligro de muerte en caso de no observar las siguientes indicaciones de seguridad!</p> <p>Los productos no se pueden poner en servicio hasta después de haber leído por completo, comprendido y tenido en cuenta la documentación y las advertencias de seguridad que se incluyen en la entrega.</p> <p>Si no dispusiera de documentación en el idioma de su país, diríjase a su distribuidor competente de Rexroth.</p> <p>Solo el personal debidamente cualificado puede trabajar en componentes de accionamiento.</p> <p>Encontrará más detalles sobre las indicaciones de seguridad en el capítulo 1 de esta documentación.</p>	<p>ATENÇÃO Perigo de vida em caso de inobservância das seguintes instruções de segurança!</p> <p>Utilize apenas os produtos depois de ter lido, compreendido e tomado em consideração a documentação e as instruções de segurança fornecidas juntamente com o produto.</p> <p>Se não tiver disponível a documentação na sua língua, dirija-se ao seu parceiro de venda responsável da Rexroth.</p> <p>Apenas pessoal qualificado pode trabalhar nos componentes de acionamento.</p> <p>Explicações mais detalhadas relativamente às instruções de segurança constam no capítulo 1 desta documentação.</p>	<p>AVVERTENZA Pericolo di morte in caso di inosservanza delle seguenti indicazioni di sicurezza!</p> <p>Mettere in funzione i prodotti solo dopo aver letto, compreso e osservato per intero la documentazione e le indicazioni di sicurezza fornite con il prodotto.</p> <p>Se non dovesse essere presente la documentazione nella vostra lingua, siete pregati di rivolgervi al rivenditore Rexroth competente.</p> <p>Solo personale qualificato può eseguire lavori sui componenti di comando.</p> <p>Per ulteriori spiegazioni riguardanti le indicazioni di sicurezza consultare il capitolo 1 di questa documentazione.</p>
<p>ADVERTENCIA ¡Alta tensión eléctrica! ¡Peligro de muerte por descarga eléctrica!</p> <p>Active sólo los componentes de accionamiento con el conductor protector firmemente instalado.</p> <p>Desconecte la alimentación eléctrica antes de manipular los componentes de accionamiento.</p> <p>Tenga en cuenta los tiempos de descarga de los condensadores.</p>	<p>ATENÇÃO Alta tensão elétrica! Perigo de vida devido a choque elétrico!</p> <p>Operar componentes de acionamento apenas com condutores de proteção instalados.</p> <p>Desligue a alimentação de tensão antes de aceder aos componentes de acionamento.</p> <p>Respeite os períodos de descarga dos condensadores.</p>	<p>AVVERTENZA Alta tensione elettrica! Pericolo di morte in seguito a scosse elettriche!</p> <p>Mettere in esercizio i componenti di comando solo con conduttore di messa a terra ben installato.</p> <p>Staccare l'alimentazione prima di intervenire sui componenti di comando.</p> <p>Osservare i tempi di scarica del condensatore.</p>
<p>ADVERTENCIA ¡Movimientos peligrosos! ¡Peligro de muerte!</p> <p>No permanezca en la zona de movimiento de las máquinas ni de sus piezas.</p> <p>Impida el acceso accidental de personas.</p> <p>Antes de acceder o introducir las manos en la zona de peligro, los accionamientos se tienen que haber parado con seguridad.</p>	<p>ATENÇÃO Movimentos perigosos! Perigo de vida!</p> <p>Não permaneça na área de movimentação das máquinas e das peças das máquinas.</p> <p>Evite o acesso involuntário para pessoas.</p> <p>Antes de entrar ou aceder à área perigosa, imobilize os acionamentos de forma segura.</p>	<p>AVVERTENZA Movimenti pericolosi! Pericolo di morte!</p> <p>Non sostare nelle zone di manovra delle macchine e delle loro parti.</p> <p>Impedire un accesso non autorizzato per le persone.</p> <p>Prima di accedere alla zona di pericolo, arrestare e bloccare gli azionamenti.</p>

E Español	P Português	I Italiano
<p>ADVERTENCIA ¡Campos electromagnéticos/magnéticos! ¡Peligro para la salud de las personas con marcapasos, implantes metálicos o audífonos!</p> <p>El acceso de las personas arriba mencionadas a las zonas de montaje o funcionamiento de los componentes de accionamiento está prohibido, salvo que lo autorice previamente un médico.</p>	<p>ATENÇÃO Campos eletromagnéticos / magnéticos! Perigo de saúde para pessoas com marcapassos, implantes metálicos ou aparelhos auditivos!</p> <p>Acesso às áreas, nas quais os componentes de acionamento são montados e operados, é proibido para as pessoas em cima mencionadas ou apenas após permissão de um médico.</p>	<p>AVVERTENZA Campi elettromagnetici / magnetici! Pericolo per la salute delle persone portatrici di pacemaker, protesi metalliche o apparecchi acustici!</p> <p>L'accesso alle zone in cui sono installati o in funzione componenti di comando è vietato per le persone sopra citate o consentito solo dopo un colloquio con il medico.</p>
<p>ATENCIÓN ¡Superficies calientes (> 60 °C)! ¡Peligro de quemaduras!</p> <p>Evite el contacto con las superficies calientes (p. ej., disipadores de calor). Observe el tiempo de enfriamiento de los componentes de accionamiento (mín. 15 minutos).</p>	<p>CUIDADO Superfícies quentes (> 60 °C)! Perigo de queimaduras!</p> <p>Evite tocar superfícies metálicas (p. ex. radiadores). Respeite o tempo de arrefecimento dos componentes de acionamento (mín. 15 minutos).</p>	<p>ATTENZIONE Superfici bollenti (> 60 °C)! Pericolo di ustioni!</p> <p>Evitare il contatto con superfici metalliche (ad es. dissipatori di calore). Rispettare i tempi di raffreddamento dei componenti di comando (almeno 15 minuti).</p>
<p>ATENCIÓN ¡Manipulación inadecuada en el transporte y montaje! ¡Peligro de lesiones!</p> <p>Utilice dispositivos de montaje y de transporte adecuados.</p> <p>Utilice herramientas adecuadas y equipo de protección personal.</p>	<p>CUIDADO Manejo incorrecto no transporte e montagem! Perigo de ferimentos!</p> <p>Utilize dispositivos de montagem e de transporte adequados.</p> <p>Utilize ferramentas e equipamento de proteção individual adequados.</p>	<p>ATTENZIONE Manipolazione inappropriata durante il trasporto e il montaggio! Pericolo di lesioni!</p> <p>Utilizzare dispositivi di montaggio e trasporto adatti.</p> <p>Utilizzare attrezzi adatti ed equipaggiamento di protezione personale.</p>
<p>ATENCIÓN ¡Manejo inadecuado de las pilas! ¡Peligro de lesiones!</p> <p>No trate de reactivar o cargar pilas descargadas (peligro de explosión y cauterización).</p> <p>No desarme ni dañe las pilas. No tire las pilas al fuego.</p>	<p>CUIDADO Manejo incorrecto de baterias! Perigo de ferimentos!</p> <p>Não tente reativar nem carregar baterias vazias (perigo de explosão e de queimaduras com ácido).</p> <p>Não desmonte nem danifique as baterias. Não deite as baterias no fogo.</p>	<p>ATTENZIONE Utilizzo inappropriato delle batterie! Pericolo di lesioni!</p> <p>Non tentare di riattivare o ricaricare batterie scariche (pericolo di esplosione e corrosione).</p> <p>Non scomporre o danneggiare le batterie. Non gettare le batterie nel fuoco.</p>

S Svenska	DK Dansk	NL Nederlands
<p>WARNING Livsfara om följande säkerhetsanvisningar inte följs!</p> <p>Använd inte produkterna innan du har läst och förstått den dokumentation och de säkerhetsanvisningar som medföljer produkten, och följ alla anvisningar.</p> <p>Kontakta din Rexroth-återförsäljare om dokumentationen inte medföljer på ditt språk.</p> <p>Endast kvalificerad personal får arbeta med drivkomponenterna.</p> <p>Se kapitel 1 i denna dokumentation för närmare beskrivningar av säkerhetsanvisningarna.</p>	<p>ADVARSEL Livsfare ved manglende overholdelse af nedenstående sikkerhedsanvisninger!</p> <p>Tag ikke produktet i brug, før du har læst og forstået den dokumentation og de sikkerhedsanvisninger, som følger med produktet, og overhold de givne anvisninger.</p> <p>Kontakt din Rexroth-forhandler, hvis dokumentationen ikke medfølger på dit sprog.</p> <p>Det er kun kvalificeret personale, der må arbejde på drive components.</p> <p>Nærmere forklaringer til sikkerhedsanvisningerne fremgår af kapitel 1 i denne dokumentation.</p>	<p>WAARSCHUWING Levensgevaar bij niet-naleving van onderstaande veiligheidsinstructies!</p> <p>Stel de producten pas in bedrijf nadat u de met het product geleverde documenten en de veiligheidsinformatie volledig gelezen, begrepen en in acht genomen heeft.</p> <p>Mocht u niet beschikken over documenten in uw landstaal, kunt u contact opnemen met uw plaatselijke Rexroth distributiepartner.</p> <p>Uitsluitend gekwalificeerd personeel mag aan de aandrijvingscomponenten werken.</p> <p>Meer informatie over de veiligheidsinstructies vindt u in hoofdstuk 1 van deze documentatie.</p>
<p>WARNING Hög elektrisk spänning! Livsfara genom elchock!</p> <p>Använd endast drivkomponenterna med fastmonterad skyddsledare.</p> <p>Koppla bort spänningsförsörjningen före arbete på drivkomponenter.</p> <p>Var medveten om kondensatorernas urladdningstid.</p>	<p>ADVARSEL Elektrisk højspænding! Livsfare på grund af elektrisk stød!</p> <p>Drive components må kun benyttes med et fast installeret jordstik.</p> <p>Sørg for at koble spændingsforsyningen fra, inden du rører ved drive components.</p> <p>Overhold kondensatorernes afladningstider.</p>	<p>WAARSCHUWING Hoge elektrische spanning! Levensgevaar door elektrische schok!</p> <p>Bedien de aandrijvingscomponenten uitsluitend met vast geïnstalleerde aardleiding.</p> <p>Schakel voor toegang tot aandrijvingscomponenten de spanningsvoorziening uit.</p> <p>Neem de ontlaadtijden van condensatoren in acht.</p>

S Svenska	DK Dansk	NL Nederlands
AVARNING Farliga rörelser! Livsfara! Uppehåll dig inte inom maskiners och maskindelars rörelseområde. Förhindra att obehöriga personer får tillträde. Innan du börjar arbeta eller vistas inom drivsystemets riskområde måste maskinen vara stillastående.	ADVARSEL Farlige bevægelser! Livsfare! Du må ikke opholde dig inden for maskiners og maskindeles bevægelsesradius. Sørg for, at ingen personer kan få utsigtet adgang. Stands drevene helt, inden du rører ved drevene eller træder ind i deres fareområde.	WAARSCHUWING Risicovolle bewegingen! Levensgevaar! Houdt u niet op in het bewegingsbereik van machines en machineonderdelen. Voorkom dat personen onbedoeld toegang krijgen. Voor toegang tot de gevaarlijke zone moeten de aandrijvingen veilig tot stilstand gebracht zijn.
AVARNING Elektromagnetiska/magnetiska fält! Hälsofaror för personer med pacemaker, implantat av metall eller hörapparat! Det är förbjudet för ovan nämnda personer (eller kräver överläggning med läkare) att beträda områden där drivkomponenter är monterade och i drift.	ADVARSEL Elektromagnetiske/magnetiske felter! Sundhedsfare for personer med pacemakere, metalliske implantater eller høreapparater! For disse personer er der adgang forbudt eller kun adgang med tilladelse fra læge til de områder, hvor drive components monteres og drives.	WAARSCHUWING Elektromagnetische / magnetische velden! Gevaar voor de gezondheid van personen met pacemakers, metalen implantaten of hoorapparaten! Toegang tot gebieden, waarin aandrijvingscomponenten worden gemonteerd en bediend, is verboden voor voornoemde personen of uitsluitend toegestaan na overleg met een arts.
OBSERVERA Varma ytor (> 60 °C)! Risk för brännskador! Undvik att vidröra metallytor (t.ex. kylelement). Var medveten om att det tar tid för drivkomponenterna att svalna (minst 15 minuter).	FORSIGTIG Varme overflader (> 60 °C)! Risiko for forbrændinger! Undgå at berøre metaloverflader (f.eks. kølelementer). Overhold drive components nedkølingstid (min. 15 min.).	VOORZICHTIG Hete oppervlakken (> 60 °C)! Verbrandingsgevaar! Voorkom contact met metalen oppervlakken (bijv. Koellichamen). Afkoeltijd van de aandrijvingscomponenten in acht nemen (min. 15 minuten).
OBSERVERA Felaktig hantering vid transport och montering! Skaderisk! Använd passande monterings- och transportanordningar. Använd lämpliga verktyg och personlig skyddsutrustning.	FORSIGTIG Fejlhåndtering ved transport og montering! Risiko for kvestelser! Benyt egnede monterings- og transportanordninger. Benyt egnet værktøj og personligt sikkerhedsudstyr.	VOORZICHTIG Onjuist gebruik bij transport en montage! Letselgevaar! Gebruik geschikte montage- en transportinrichtingen. Gebruik geschikt gereedschap en een persoonlijke veiligheidsuitrusting.
OBSERVERA Felaktig hantering av batterier! Skaderisk! Försök inte återaktivera eller ladda upp batterier (risk för explosioner och frätskador). Batterierna får inte tas isär eller skadas. Släng inte batterierna i elden.	FORSIGTIG Fejlhåndtering af batterier! Risiko for kvæstelser! Forsøg ikke at genaktivere eller oplade tomme batterier (eksplosions- og ætsningsfare). Undlad at skille batterier ad eller at beskadige dem. Smid ikke batterier ind i åben ild.	VOORZICHTIG Onjuist gebruik van batterijen! Letselgevaar! Probeer nooit lege batterijen te reactiveren of op te laden (explosiegevaar en gevaar voor beschadiging van weefsel door cauterisatie). Batterijen niet demonteren of beschadigen. Nooit batterijen in het vuur werpen.

 Suomi	 Polski	 Český
<p>AVAROITUS Näiden turvaohjeiden noudattamatta jättämisestä on seurausena hengenvaara!</p> <p>Ota tuote käyttöön vasta sen jälkeen, kun olet lukenut läpi tuotteen mukana toimitetut asiakirjat ja turvallisuusohjeet, ymmärtänyt ne ja ottanut ne huomioon.</p> <p>Jos asiakirjoja ei ole saatavana omalla äidinkielelläsi, ota yhteys asianomaiseen Rexrothin myyntiedustajaan.</p> <p>Käyttölaitteiden komponenttien parissa saa työskennellä ainoastaan valtuuttetu henkilöstö.</p> <p>Lisätietoa turvaohjeista löydät tämän dokumentaation luvusta 1.</p>	<p>OSTRZEŻENIE Zagrożenie życia w razie nieprzestrzegania poniższych wskazówek bezpieczeństwa!</p> <p>Nie uruchamiać produktów przed uprzednim przeczytaniem i pełnym zrozumieniem wszystkich dokumentów dostarczonych wraz z produktem oraz wskazówek bezpieczeństwa. Należy przestrzegać wszystkich zawartych tam zaleceń.</p> <p>W przypadku braku dokumentów w Państwa języku, prosimy o skontaktowanie się z lokalnym partnerem handlowym Rexroth.</p> <p>Przy zespołach napędowych może pracować wyłącznie wykwalifikowany personel.</p> <p>Bliższe objaśnienia wskazówek bezpieczeństwa znajdują się w Rozdziale 1 niniejszej dokumentacji.</p>	<p>VAROVÁNÍ Nebezpečí života v případě nedodržení níže uvedených bezpečnostních pokynů!</p> <p>Před uvedením výrobků do provozu si přečtěte kompletní dokumentaci a bezpečnostní pokyny dodávané s výrobkem, pochopte je a dodržujte.</p> <p>Nemáte-li k dispozici podklady ve svém jazyce, obraťte se na příslušného obchodního partnera Rexroth.</p> <p>Na komponentách pohonu smí pracovat pouze kvalifikovaný personál.</p> <p>Podrobnější vysvětlení k bezpečnostním pokynům naleznete v kapitole 1 této dokumentace.</p>
<p>AVAROITUS Voimakas sähköjännite! Sähköiskun alheuttama hengenvaara!</p> <p>Käytä käyttölaitteen komponentteja ainoastaan maadoitusjohtimen ollessa kiinteästi asennettuna.</p> <p>Katkaise jännitteensyöttö ennen käyttölaitteen komponenteille suoritettavien töiden aloittamista.</p> <p>Huomioi kondensaattoreiden purkausajat.</p>	<p>OSTRZEŻENIE Wysokie napięcie elektryczne! Zagrożenie życia w wyniku porażenia prądem!</p> <p>Zespoły napędu mogą być eksploatowane wyłącznie zainstalowanym na stałe przewodem ochronnym.</p> <p>Przed uzyskaniem dostępu do podzespołów napędu należy odłączyć zasilanie elektryczne.</p> <p>Zwracać uwagę na czas rozładowania kondensatorów.</p>	<p>VAROVÁNÍ Vysoké elektrické napětí! Nebezpečí života při zasažení elektrickým proudem!</p> <p>Komponenty pohonu smí být v provozu pouze s pevně nainstalovaným ochranným vodičem.</p> <p>Než začnete zasahovat do komponent pohonu, odpojte je od elektrického napájení. Dodržujte vybíjecí časy kondenzátorů.</p>
<p>AVAROITUS Vaarallisia liikkeitä! Hengenvaara!</p> <p>Älä oleskele koneiden tai koneenosien liikealueella.</p> <p>Pidä huolta siitä, ettei muita henkilötä pääse alueelle vahingossa.</p> <p>Pysätyt käyttölaitteet varmasti ennen vaara-alueelle koskemista tai menemistä.</p>	<p>OSTRZEŻENIE Niebezpieczne ruchy! Zagrożenie życia!</p> <p>Nie wolno przebywać w obszarze pracy maszyny i jej elementów.</p> <p>Nie dopuszczać osób niepowołanych do obszaru pracy maszyny.</p> <p>Przed dotknięciem urządzenia/maszyny lub zbliżeniem się do obszaru zagrożenia należy zgodnie z zasadami bezpieczeństwa wyłączyć napędy.</p>	<p>VAROVÁNÍ Nebezpečné pohyby! Nebezpečí života!</p> <p>Nezdržujte se v dosahu pohybu strojů a jejich součástí.</p> <p>Zabraňte náhodnému přístupu osob. Před zásahem nebo vstupem do nebezpečného prostoru bezpečně zastavte pohon.</p>
<p>AVAROITUS Sähkömagneettisia/magneettisia kenttiä! Terveydellisten haittojen vaara henkilöille, joilla on sydämentahdistin, metallinen implantti tai kulolaitite!</p> <p>Yllä mainituilta henkilöiltä on pääsy kielletty alueille, joilla asennetaan tai käytetään käyttölaitteen komponentteja, tai heidän on ensin saatava tähän suostumus lääkäriltään.</p>	<p>OSTRZEŻENIE Pola elektromagnetyczne / magnetyczne! Zagrożenie zdrowia dla osób z rozrusznikiem serca, metalowymi implantami lub aparatomi słuchowymi!</p> <p>Wstęp na teren, gdzie odbywa się montaż i eksploatacja napędów jest dla ww. osób zabroniony względnie dozwolony po konsultacji z lekarzem.</p>	<p>VAROVÁNÍ Elektromagnetická/magnetická pole! Nebezpečí pro zdraví osob s kardiostimulátory, kovovými implantáty nebo naslouchadly!</p> <p>Výše uvedené osoby mají zakázán přístup do prostorů, kde jsou montovány a používány komponenty pohonu, resp. ho mají povolen pouze po poradě s lékařem.</p>
<p>AHUOMIO Kuumia pintoja (> 60 °C)! Palovammojen vaara!</p> <p>Vältä metallipintojen koskettamista (esim. jäähdytyslevyt). Noudata käyttölaitteen komponenttien jäähtymisaikoja (väh. 15 minuuttia).</p>	<p>PRZESTROGA Gorące powierzchnie (> 60 °C)! Niebezpieczeństwo poparzenia!</p> <p>Unikać kontaktu z powierzchniami metalowymi (np. radiatorami). Przestrzegać czasów schładzania podzespołów napędów (min. 15 minut).</p>	<p>UPOZORNĚNÍ Horké povrchy (> 60 °C)! Nebezpečí popálení!</p> <p>Nedotýkejte se kovových povrchů (např. chladicích těles). Dodržujte dobu ochlazení komponent pohonu (min. 15 minut).</p>

 Suomi	 Polski	 Český
<p>A HUOMIO Epäasianmukainen käsitteily kuljetuksen ja asennuksen yhteydessä! Loukkaantumisvaara!</p> <p>Käytä soveltuvia asennus- ja kuljetuslaitteita.</p> <p>Käytä omia työkaluja ja henkilökohtaisia suojaravusteita.</p>	<p>A PRZESTROGA Niewłaściwe obchodzenie się podczas transportu i montażu! Ryzyko urazu!</p> <p>Stosować odpowiednie urządzenia montażowe i transportowe.</p> <p>Stosować odpowiednie narzędzia i środki ochrony osobistej.</p>	<p>A UPOZORNĚNÍ Nesprávné zacházení při přepravě a montáži! Nebezpečí zranění!</p> <p>Používejte vhodná montážní a dopravní zařízení.</p> <p>Používejte vhodné náradí a osobní ochranné vybavení.</p>
<p>A HUOMIO Paristojen epäasianmukainen käsitteily! Loukkaantumisvaara!</p> <p>Älä yritä saada tyhjiä paristoja toimimaan tai ladata niitä uudelleen (räjähdyks- ja syöpymisvaara).</p> <p>Älä hajota paristoja osiin tai vaurioita niitää. Älä heitä paristoja tuleen.</p>	<p>A PRZESTROGA Niewłaściwe obchodzenie się z bateriami! Ryzyko urazu!</p> <p>Nie próbować reaktywować i nie ładować zużytych baterii (niebezpieczeństwo wybuchu oraz poparzenia żrącą substancją).</p> <p>Nie demontać i nie niszczyć baterii. Nie wrzucać baterii do ognia.</p>	<p>A UPOZORNĚNÍ Nesprávné zacházení s bateriami! Nebezpečí zranění!</p> <p>Nepokoušejte se znova aktivovat nebo dobýt prázdné baterie (nebezpečí výbuchu a poleptání).</p> <p>Nerozebírejte ani nepoškozujte baterie. Neházejte baterie do ohně.</p>

 Slovensko	 Slovenčina	 Română
<p>A OPOZORILO Življenjska nevarnost pri neupoštevanju naslednjih napotkov za varnost!</p> <p>Izdelke začnite uporabljati šele, ko v celoti preberete, razumete in upoštevate izdelkom priloženo dokumentacijo in varnostne napotke.</p> <p>Če priložena dokumentacija ni na voljo v vašem maternem jeziku, se obrnite na pristojnega distributerja Rexroth.</p> <p>Samo kvalificirano osebje sme delati na pogonskih komponentah.</p> <p>Podrobnejša pojasnila o varnostnih navodilih najdete v poglavju 1 v tej dokumentaciji.</p>	<p>A VAROVANIE Nebezpečenstvo ohrozenia života pri nedodržiavaní nasledujúcich bezpečnostných pokynov!</p> <p>Výrobky uvádzajte do prevádzky až potom, čo ste úplne prečítali, pochopili a zobrať do úvahy podklady a bezpečnostné pokyny dodané s výrobkom.</p> <p>Ak by ste nemali k dispozícii žiadne podklady v jazyku svojej krajiny, obráťte sa prosím na svojho príslušného predajcu Rexroth.</p> <p>Na komponentoch pohonu smie pracovať iba kvalifikovaný personál.</p> <p>Bližšie vysvetlenia k bezpečnostným pokynom zistite z kapitoly 1 tejto dokumentácie.</p>	<p>A AVERTIZARE Pericol de moarte în cazul nerespectării următoarelor instrucțiuni de siguranță!</p> <p>Punerea în funcțiune a produselor trebuie efectuată după citirea, înțelegerea și respectarea documentelor și instrucțiunilor de siguranță, care sunt livrate împreună cu produsele.</p> <p>În cazul în care documentele nu sunt în limba dumneavoastră maternă, vă rugăm să contactați partenerul de vânzări Rexroth.</p> <p>Numai un personal calificat poate lucra cu componente de acționare.</p> <p>Explicații detaliate privind instrucțiunile de siguranță găsiți în capitolul 1 al acestei documentații.</p>
<p>A OPOZORILO Visoka električna napetost! Življenjska nevarnost zaradi električnega udara!</p> <p>Pogonske komponente uporabljajte samo s fiksno nameščenim zaščitnim vodnikom.</p> <p>Pred dostopom do pogonske komponente odklopite napajanje.</p> <p>Upoštevajte čase praznjenja kondenzatorjev.</p>	<p>A VAROVANIE Vysoké elektrické napätie! Nebezpečenstvo ohrozenia života v dôsledku zásahu elektrickým prúdom!</p> <p>Komponenty pohonu prevádzkujte iba s pevnou nainštalovanou ochrannou vodičom.</p> <p>Pred prístupom na komponenty pohonu odpojte zdroj napäcia.</p> <p>Rešpektujte časy vybitia kondenzátorov.</p>	<p>A AVERTIZARE Tensiune electrică înaltă! Pericol de moarte prin electrocutare!</p> <p>Exploatați componente de acționare numai cu împământarea instalată permanent.</p> <p>Înainte de intervenția asupra componentelor de acționare, deconectați alimentarea cu tensiune electrică.</p> <p>Tineți cont de timpii de descărcare ai condensatorilor.</p>
<p>A OPOZORILO Nevarni premiki! Življenjska nevarnost!</p> <p>Ne zadržujte se v območju delovanja strojev.</p> <p>Preprečite nenadzorovan dostop oseb.</p> <p>Pred prijemom ali dostopom v nevarno območje varno zaustavite vse gnane dele.</p>	<p>A VAROVANIE Pohyby prinášajúce nebezpečenstvo! Nebezpečenstvo ohrozenia života!</p> <p>Nezdržiavajte sa v oblasti pohybu strojov a častí strojov.</p> <p>Zabráňte nepovolanému prístupu osôb.</p> <p>Pred zásahom alebo prístupom do nebezpečnej oblasti uvedťte pohony bezpečne do zastavenia.</p>	<p>A AVERTIZARE Mișcări periculoase! Pericol de moarte!</p> <p>Nu staționați în zona de mișcare a mașinilor și a componentelor în mișcare a mașinilor.</p> <p>Împiedicați accesul neintenționat al persoanelor în zona de lucru a mașinilor.</p> <p>Înainte de intervenția sau accesul în zona periculoasă, opriți în siguranță componente de acționare.</p>

SLO Slovensko	SK Slovenčina	RO Română
<p>⚠️ APOZORILO Elektromagnetna / magnetna polja! Nevarnost za zdravje za osebe s spodbujevalniki srca, kovinskimi vsadki ali slušními aparati!</p> <p>Dostop do območij, v katerih so nameščene delijoče pogonske komponente, je za zgoraj navedene osebe prepovedan oz. dovoljen samo po posvetu z zdravnikom.</p>	<p>⚠️ VAROVANIE Elektromagnetické/ magnetické polia! Nebezpečenstvo pre zdravie osôb s kardiostimulátormi, kovovými implantaťmi alebo načúvacimi prístrojmi!</p> <p>Prístup k oblastiam, v ktorých sú namontované a prevádzkujú sa komponenty pohunu, je pre hore uvedené osoby zakázaný resp. je dovolený iba po konzultácii s lekárom.</p>	<p>⚠️ AVERTIZARE Câmpuri electromagnetice / magnetice! Pericol pentru sănătatea persoanelor cu stimulatoare cardiace, implanturi metalice sau aparatelor auditivel!</p> <p>Intrarea în zone, în care se montează sau se exploatează componente de acționare, este interzisă pentru persoanele sus numite respectiv este permisă numai cu acordul medicului.</p>
<p>⚠️ POZOR Vročé površine (> 60 °C)! Nevarnost opéklin!</p> <p>Izogibajte se stiku s kovinskimi površinami (npr. hladilními telesí). Upoštevajte čas hlajenia pogonských komponent (najm. 15 minút).</p>	<p>⚠️ UPOZORNENIE Horúce povrchy (> 60 °C)! Nebezpečenstvo popálenia!</p> <p>Zabráňte kontaktu s kovovými povrchmi (napr. chladiacimi telesami). Dodržiavajte čas vychladenia komponentov pohunu (min. 15 minút).</p>	<p>⚠️ ATENȚIE Suprafețe fierbinți (> 60 °C)! Pericol de arsuri!</p> <p>Nu atingeți suprafețele metalice (de ex. radiatoare de răcire). Respectați timpul de răcire ai componentelor de acționare (min. 15 minute).</p>
<p>⚠️ POZOR Nastrokovno ravnanje med transportom in namestitvijo! Nevarnost poškodb!</p> <p>Uporabljajte ustrezne pripomočke za nameščanje in transport.</p> <p>Uporabite ustrezno orodje in osebno zaščitno opremo.</p>	<p>⚠️ UPOZORNENIE Neodborná manipulácia pri transporte a montáži! Nebezpečenstvo poranenia!</p> <p>Používajte vhodné montážne a transportné zariadenia.</p> <p>Používajte vhodné náradie a osobné ochranné prostriedky.</p>	<p>⚠️ ATENȚIE Manipulare necorespunzătoare la transport și montaj! Pericol de vătămare!</p> <p>Utilizați dispozitive adecvate de montaj și transport.</p> <p>Folosiți instrumente corespunzătoare și echipament personal de protecție.</p>
<p>⚠️ POZOR Nepravilno ravnanje z baterijami! Nevarnost poškodb!</p> <p>Ne poskušajte ponovno aktivirati ali napolnitи praznih baterij (Nevarnost zaradi eksploziej ali jedkanja).</p> <p>Ne razstavljajte ali poškodujte nobenih baterij. Baterij ne mečite v ogenj.</p>	<p>⚠️ UPOZORNENIE Neodborná manipulácia s batériami! Nebezpečenstvo poranenia!</p> <p>Nepokújajte sa reaktivovať alebo nabíjať prázdne batérie (nebezpečenstvo výbuchu a poleptania).</p> <p>Batérie nerozoberajte ani nepoškodzujte. Nehádžte batérie do ohňa.</p>	<p>⚠️ ATENȚIE Manipulare necorespunzătoare a bateriilor! Pericol de vătămare!</p> <p>Nu încercați să reactivați sau să încărcați bateriile goale (pericol de explozie și pericol de arsuri).</p> <p>Nu dezasamblați și nu deteriorați bateriile. Nu aruncați bateriile în foc.</p>

H Magyar	BG Български	LV Latviski
<p>⚠️ FIGYELMEZTETÉSI Az alábbi biztonsági útmutatások figyelmen kívül hagyása életveszélyes helyzethez vezethet!</p> <p>Üzembe helyezés előtt olvassa el, értelmezze, és vegye figyelembe a csomagban található dokumentumban foglaltakat és a biztonsági útmutatásokat.</p> <p>Amennyiben a csomagban nem talál az Ön nyelvén írt dokumentumokat, vegye fel a kapcsolatot az illetékes Rexroth-képviselővel.</p> <p>A hajtás alkatrészein kizárolag képzett személy dolgozhat.</p> <p>A biztonsági útmutatókkal kapcsolatban további magyarázatot ennek a dokumentumnak az első fejezetében találhat.</p>	<p>⚠️ ПРЕДУПРЕЖДЕНИЕ Опасност за живота при неспазване на посочените подолу инструкции за безопасност!</p> <p>Използвайте продуктите след като сте се запознали подробно с приложената към продукта документация и указания за безопасност, разбрали сте ги и сте се съобразили с тях.</p> <p>Ако текстът не е написан на Вашия език, моля обърнете се към Вашия компетентен търговски представител на Rexroth.</p> <p>Със задвижващите компоненти трябва да работи само квалифициран персонал.</p> <p>Подробни пояснения към инструкциите за безопасност можете да видите в Глава 1 на тази документация.</p>	<p>⚠️ BRĪDINĀJUMS Turpinājumā doto drošības norādījumu neievērošana var apdraudēt dzīvību!</p> <p>Sāciet lietot izstrādājumu tikai pēc tam, kad esat pilnībā izlasijsi, sapratusi un nēmuši vērā kopā ar izstrādājumu piegādātos dokumentus.</p> <p>Ja dokumenti nav pieejami Jūsu valsts valodā, vērsieties pie pilnvarotā Rexroth izplātnītāja.</p> <p>Darbus pie piedziņas komponentiem drīkst veikt tikai kvalificēts personāls.</p> <p>Detalizētus paskaidrojumus attiecībā uz drošības norādījumiem skatiet šī dokumenta 1. nodalājā.</p>
<p>⚠️ FIGYELMEZTETÉSI Magas elektromos feszültség! Életveszély áramütés miatt!</p> <p>A hajtás alkatrészeit csak vélegesen telepített védővezetővel üzemeltesse!</p> <p>Mielőtt hozzájárul a hajtás alkatrészeihez, kapcsolja ki az áramellátást.</p> <p>Ügyeljen a kondenzátorok kisülési idejére!</p>	<p>⚠️ ПРЕДУПРЕЖДЕНИЕ Високо електрическо напрежение! Опасност за живота от удар от електрически ток!</p> <p>Работете със задвижващите компоненти само при здраво закрепен заземляващ проводник.</p> <p>Преди работа по задвижващите компоненти, изключете захранващото напрежение.</p> <p>Обърнете внимание на времето за разреждане на кондензаторите.</p>	<p>⚠️ BRĪDINĀJUMS Augsts elektriskais spriegums! Dzīvības apdraudējums elektriskā triecienu dēļ!</p> <p>Piedziņas komponentus darbiniet tikai ar fiksēti uzstādītu zemējumvadu.</p> <p>Pirms darba pie piedziņas komponentiem atslēdziet elektroapgādi.</p> <p>Nemiet vērā kondensatoru izlādes laikus.</p>

H Magyar	BG Български	LV Latviski
⚠ FIGYELMEZTETÉS! Veszélyes mozgás! Életveszély!	⚠ ПРЕДУПРЕЖДЕНИЕ Опасни движения! Опасност за живота!	⚠ BRĪDINĀJUMS Bīstamas kustības! Dzīvības apdraudējums!
Ne tartózkodjon a gépek és a gépalkatrészek mozgási területén belül! Illetéktelen személyeket ne engedjen a géközelébe! Mielőtt beavatkozik, vagy a veszélyes zónába belép a hajtásokat biztonságosan állítsa le.	Не стойте в обсега на движение на машините и частите на машините. Не допускайте непреднамерен достъп на хора. Преди работа или влизане в опасната зона, спрете надеждно приводния механизъм.	Neuzturieties mašīnu un mašīnas detaļu kustību zonā. Novērsiet nepiederošu personu piekļūšanu. Pirms darba bīstamajās zonās pilnībā apstādiniet piedziņu.
⚠ FIGYELMEZTETÉS! Elektromágneses / mágneses mező! Káros hatással lehet a szívritmus-szabályozó készülékkel, fémbeültetéssel vagy hallókészülékkel rendelkezők egészségére!	⚠ ПРЕДУПРЕЖДЕНИЕ Електромагнитни / магнитни полета! Опасност за здравето на хора със сърдечни стимулатори, метални импланти или слухови апарати!	⚠ BRĪDINĀJUMS Elektromagnētiskais / magnētiskais lauks! Veselības apdraudējums personām ar sirds stimulatoriem, metāliskiem implantiem vai dzirdes aparātiem!
Azokra a területekre, ahol hajtások alkatrészeit szerelik és üzemeltetik, a fent említett személyeknek tilos a belépés, illetve csak orvosi konzultációt követően szabad az adott területekre lépniük.	Достъпът за гореспоменатите лица до зони, в които ще се монтират и ще работят задвижващи компоненти се забранява, или разрешава само след консултация с лекар.	Tuvošanās zonām, kurās tiek montēti un darbināti piedziņas komponenti, iepriekš minētajām personām ir aizliegta, respektīvi, atļauta tikai pēc konsultēšanās ar ārstu.
⚠ VIGYÁZAT! Forró felületek (> 60 °C)! Égésveszély!	⚠ ВНИМАНИЕ Горещи повърхности (> 60 °C)! Опасност от изгаряне!	⚠ UZMANĪBU Karstas virsmas (> 60 °C)! Apdedzināšanās risks!
Ne érjen hozzá fémfelületekhez (pl. hűtőtestekhez)! Vegye figyelembe a hajtás alkatrészeinek kihűlési idejét (min. 15 perc)!	Не докосвайте метални повърхности (например радиатори). Съблюдавайте времето на охлаждане на задвижващите компоненти (мин. 15 минути).	Neskarieties pie metaliskām virsmām (piemēram, дзесētāja). Iaujiet piedziņas komponentiem atdzist (min. 15 minutes).
⚠ VIGYÁZAT! Szakszerűtlen kezelés szállításkor és szereléskor! Sérülésveszély!	⚠ ВНИМАНИЕ Неправилно боравене по време на транспорт и монтаж! Опасност от нараняване!	⚠ UZMANĪBU Nepareizi velkta transportēšana un montāža! Traumu gūšanas risks!
A megfelelő beszerelési és szállítási eljárásokat alkalmazza! Használjon megfelelő szerszámokat és személyes védőfelszerelést!	Използвайте подходящо монтажно и транспортно оборудване. Използвайте подходящи инструменти и лични предпазни средства.	Izmantojet piemērotas montāžas un transportēšanas ierīces. Izmantojet piemērotus instrumentus un individuālos aizsardzības līdzekļus.
⚠ VIGYÁZAT! Akkumulátorok szakszerűtlen kezelésel! Sérülésveszély!	⚠ ВНИМАНИЕ Неправилно боравене с батерии! Опасност от нараняване!	⚠ UZMANĪBU Nepareiza bateriju lietošana! Traumu gūšanas risks!
Üres akkumulátorokat ne aktiváljon újra, illetve ne töltön fel (robbanás- és marásveszély)! Az akkumulátorokat ne szedje szét, és ne rongálja meg! Az akkumulátort ne dobja tűzbe!	Не се опитвайте да активирате отново или да зареждате разредени батерии (Опасност от експлозия и напръскване с агресивен агент). Не разглобявайте и не повреждайте батерии. Не хвърляйте батерии в огън.	Nemēģiniet no jauna aktivizēt vai uzlādēt tukšas baterijas (eksploziju un kīmisko apdegumu draudi). Neizjauciet un nesabojājet baterijas. Nemetiet baterijas ugnī.

Lietuviškai	Eesti	Ελληνικά
<p>⚠ ISPĒJIMAS Pavojus gyvybei nesilaikant toliau pateikiama saugumo nurodymų!</p> <p>Naudokite gaminių tik kruopščiai perskaite prie jo pridėtus aprašus, saugumo nurodymus. Susipažinkite su jais ir vadovaukitės naudodami gaminių.</p> <p>Jei Jūs negavote aprašo gimbtaja kalba, kreipkitės į igaliotus Rexroth atstovus.</p> <p>Prie pavaros komponentų leidžiama dirbtį tik kvalifikuotam personalui.</p> <p>Išsamesnius saugumo nurodymų paaiškinimus rasite šios dokumentacijos 1 skyriuje.</p>	<p>⚠ HOIATUS Alljärgnevate ohutusjuhiste eiramise on eluohtlik!</p> <p>Võtkke tooted käiku alles siis, kui olete toodetega kaasolevad materjalid ning ohutusjuhisid täielikult läbi lugenud, neist aru saanud ja neid järginud.</p> <p>Kui Teil puuduvad emakeelsed materjalid, siis pöörduge Rexrothi kohaliku müügiesinduse poole.</p> <p>Ajamikomponentidega töhib töötada üksnes kvalifitseeritud personal.</p> <p>Täpsemaid selgitusi ohutusjuhiste kohta leiate käesoleva dokumentatsiooni peatükist 1.</p>	<p>⚠ ΠΡΟΕΙΔΟΠΟΙΗΣΗ Κίνδυνος θανάτου σε περίπτωση μη συμμόρφωσης με τις παρακάτω οδηγίες ασφαλείας!</p> <p>Θέστε το προϊόν σε λειτουργία αφού διαβάσετε, κατανοήσετε και λάβετε υπόψη το σύνολο των οδηγιών ασφαλείας που το συνοδεύουν.</p> <p>Εάν δεν υπάρχει τεκμηρίωση στη γλώσσα σας, απευθυνθείτε σε εξουσιοδοτημένο αντιπρόσωπο της Rexroth.</p> <p>Μόνο εξειδικευμένο προσωπικό επιτρέπεται να χειρίζεται στοιχεία μετάδοσης κίνησης.</p> <p>Περαιτέρω επεξηγήσεις των οδηγιών ασφαλείας διατίθενται στο κεφάλαιο 1 της παρούσας τεκμηρίωσης.</p>
<p>⚠ ISPĒJIMAS Aukšta elektros įtampa! Pavojus gyvybei dėl elektros smūgio!</p> <p>Pavaros komponentus ekspluatuokite tik su fiksuotai instaliuotu apsauginiu laidu.</p> <p>Prieš priedami prie pavaros komponentų išjunkite maitinimo įtampą.</p> <p>Atsižvelkite į kondensatorių išsikrovimo trukmę.</p>	<p>⚠ HOIATUS Kõrge elektripinge! Eluohtlik elektrilöögi tõttu!</p> <p>Käitage ajamikomponente üksnes püsivalt installeritud maandusega.</p> <p>Lülitage enne ajamikomponentidega tööde alustamist toitepinge välja.</p> <p>Järgige kondensaatorite mahalaadumisaegu.</p>	<p>⚠ ΠΡΟΕΙΔΟΠΟΙΗΣΗ Υψηλή ηλεκτρική τάση! Κίνδυνος θανάτου από ηλεκτροπλήξια!</p> <p>Θέτετε σε λειτουργία τα στοιχεία μετάδοσης κίνησης μόνο εφόσον έχει τοποθετηθεί καλά προστατευτικός αγωγός γείωσης.</p> <p>Πριν από οποιαδήποτε παρέμβαση, αποσυνδέστε την τροφοδοσία των στοιχείων μετάδοσης κίνησης.</p> <p>Λάβετε υπόψη τους χρόνους αποφόρτισης των πυκνωτών.</p>
<p>⚠ ISPĒJIMAS Pavojingi judesiai! Pavojus gyvybei!</p> <p>Nebūkite mašinų ar jų dalijų judėjimo zonoje.</p> <p>Neleiskite netycia patekti asmenims.</p> <p>Prieš patekdami į pavojaus zoną saugiai išjunkite pavaras.</p>	<p>⚠ HOIATUS Ohtlikud liikumised! Eluohtlik!</p> <p>Ärge viibige masina ja masinaosade liikumispiirkonnas.</p> <p>Tökestage inimeste ettekavatsematu sisenemine masina ja masinaosade liikumispiirkonda.</p> <p>Tagage ajamite turvaline seiskamine enne ohupiirkonda juurdepääsu või sisenemist.</p>	<p>⚠ ΠΡΟΕΙΔΟΠΟΙΗΣΗ Επικίνδυνες τάσεις! Κίνδυνος θανάτου!</p> <p>Μην στέκεστε στην περιοχή κίνησης μηχανημάτων και εξαρτημάτων.</p> <p>Αποτρέπετε την τυχαία είσοδο απόμων.</p> <p>Πριν από την παρέμβαση ή πρόσβαση στην περιοχή κινδύνου, μεριμνήστε για την ασφαλή ακινητοποίηση των συστημάτων μετάδοσης κίνησης.</p>
<p>⚠ ISPĒJIMAS Elektromagnetiniai / magnetiniai laukai! Pavojus asmenų su širdies stimulatoriais, metaliniu implantu arba klausos aparatais sveikatai!</p> <p>Prieiga prie zonų, kuriose montuojami ir ekspluatuojami pavaros komponentai, aukščiau nurodytiems asmenims yra draudžiama arba leista tik pasitarus su gydytoju.</p>	<p>⚠ HOIATUS Elektromagnetilised / magnetilised väljad! Terviseohilik südamestimulaatorite, metallimplantaatide ja kuulmisseadmetega inimestele!</p> <p>Sisenemine piirkondadesse, kus toimub ajamikomponentide monteerimine ja kaitamine, on üalnimetatud isikutele keelatud või lubatud üksnes pärast arstiga konsulteerimist.</p>	<p>⚠ ΠΡΟΕΙΔΟΠΟΙΗΣΗ Ηλεκτρομαγνητικά/μαγνητικά πεδία! Κίνδυνος για την υγεία ατόμων με καρδιακούς βηματοδότες, μεταλλικά εμφυτεύματα ή συσκευές ακοής!</p> <p>Η είσοδος σε περιοχές όπου πραγματοποιείται συναρμολόγηση και λειτουργία στοιχείων μετάδοσης κίνησης απαγορεύεται στα προαναφερθέντα άτομα, εκτός αν τους έχει δοθεί σχετική άδεια κατόπιν συνεννόσης με γιατρό.</p>
<p>⚠ PERSPĒJIMAS Karštī paviršiai (> 60 °C)! Nudegimo pavojus!</p> <p>Venkite liesti metalinius paviršius (pvz., radiatorius). Išlaikykite pavaros komponentų atvésimo trukmę (bent 15 minučių).</p>	<p>⚠ ETTEVAATUST Kuumad välispinnad (> 60 °C)! Põletusoht!</p> <p>Vältige metalsete välispindade (nt radiaatorid) puudutamist. Pidage kinni ajamikomponentide mahajahtumisajast (vähemalt 15 minutit).</p>	<p>⚠ ΠΡΟΣΟΧΗ Καυτές επιφάνειες (> 60 °C)! Κίνδυνος εγκαύματος!</p> <p>Αποφεύγετε την επαφή με μεταλλικές επιφάνειες (π.χ. μονάδες ψύξης). Λάβετε υπόψη το χρόνο ψύξης των στοιχείων μετάδοσης κίνησης (τουσάχιστον 15 λεπτά).</p>

Lietuviškai	Eesti	Ελληνικά
<p>⚠ PERSPĒJIMAS Netinkamas darbas transportuojant ir montuojant! Susižalojimo pavojus!</p> <p>Naudokite tinkamus montavimo ir transportavimo įrenginius.</p> <p>Naudokite tinkamus irankius ir asmens saugos priemones.</p>	<p>⚠ ETTEVAATUST Asjatundmatu käsitsemine transportimisel ja montaažil! Vigastusoht!</p> <p>Kasutage sobivaid montaaži- ja transportsedisseid.</p> <p>Kasutage sobivaid tööriisti ja isiklikku kaitsevarustust.</p>	<p>⚠ ΠΡΟΣΟΧΗ Ακατάλληλος χειρισμός κατά τη μεταφορά και συναρμολόγηση! Κίνδυνος τραυματισμού!</p> <p>Χρησιμοποιείτε κατάλληλους μηχανισμούς συναρμολόγησης και μεταφοράς.</p> <p>Χρησιμοποιείτε κατάλληλα εργαλεία και ατομικό εξοπλισμό προστασίας.</p>
<p>⚠ PERSPĒJIMAS Netinkamas darbas su baterijomis! Susižalojimo pavojus!</p> <p>Nebandykite tuščių baterijų reaktyvuoti arba ijkrauti (sprogimo ir išėsdinimo pavojus).</p> <p>Neardykitė ir nepažeiskite baterijų.</p> <p>Nemeskite baterijų į ugnį.</p>	<p>⚠ ETTEVAATUST Patareide asjatundmatu käsitsemine! Vigastusoht!</p> <p>Ärge üritage kunagi tühje patareisid reaktiveerida või täis laadida (plahvatus- ja sõövitusoht).</p> <p>Ärge demonteerige ega kahjustage patareisid. Ärge visake patareisid tulle.</p>	<p>⚠ ΠΡΟΣΟΧΗ Ακατάλληλος χειρισμός μπαταριών! Κίνδυνος τραυματισμού!</p> <p>Μην επιδιώκετε να ενεργοποιήσετε ξανά ή να φορτίσετε κενές μπαταρίες (κίνδυνος έκρηξης και διάβρωσης).</p> <p>Μην διαλύετε ή καταστρέφετε τις μπαταρίες. Μην απορρίπτετε τις μπαταρίες στη φωτιά.</p>

CN 中文
<p>⚠ 警告 如果不按照下述指定的安全说明使用，将会导致人身伤害！</p> <p>在没有阅读，理解随本产品附带的文件并熟知正当使用前，不要安装或使用本产品。</p> <p>如果没有您所在国家官方语言文件说明，请与 Rexroth 销售伙伴联系。</p> <p>只允许有资格人员对驱动器部件进行操作。</p> <p>安全说明的详细解释在本文档的第一章。</p>
<p>⚠ 警告 高电压！电击导致生命危险！</p> <p>只有在安装了永久良好的设备接地导线后才可以对驱动器的部件进行操作。</p> <p>在接触驱动器部件前先将驱动器部件断电。</p> <p>确保电容放电时间。</p>
<p>⚠ 警告 危险运动！生命危险！</p> <p>保证设备的运动区域内和移动部件周围无障碍物。</p> <p>防止人员意外进入设备运动区域内。</p> <p>在接近或进入危险区域之前，确保传动设备安全停止。</p>
<p>⚠ 警告 电磁场/磁场！对佩戴心脏起搏器、金属植入物和助听器的人员会造成严重的人身伤害！</p> <p>上述人员禁止进入安装及运行的驱动器区域，或者必须事先咨询医生。</p>
<p>⚠ 小心 热表面（大于 60 度）！灼伤风险！</p> <p>不要触摸金属表面（例如散热器）。驱动器部件断电后需要时间进行冷却（至少 15 分钟）。</p>
<p>⚠ 小心 安装和运输不当导致受伤危险！当心受伤！</p> <p>使用适当的运输和安装设备。</p> <p>使用适合的工具及用适当的防护设备。</p>
<p>⚠ 小心 电池操作不当！受伤风险！</p> <p>请勿对低电量电池重新激活或重新充电（爆炸和腐蚀的危险）。</p> <p>请勿拆解或损坏电池。请勿将电池投入明火中。</p>

Table of Contents

Table of Contents

	Page
1 About this Documentation	15
1.1 Validity of this Documentation	15
1.2 Additional Documentation	15
1.3 Presentation of Information.....	15
2 Safety Instructions	17
2.1 About this Chapter	17
2.2 Appropriate Use	17
2.3 Inappropriate Use	17
2.4 Personnel Qualification.....	17
2.5 General Safety Instructions.....	18
2.6 Product and Technology-dependent Safety Instructions	18
2.6.1 Protection against Electrical Voltage.....	18
2.6.2 Protection against Mechanical Hazards.....	18
2.6.3 Protection against Magnetic and Electromagnetic Fields.....	19
2.6.4 Protection against Burns.....	19
3 Scope of Delivery	21
4 About this Product	23
4.1 Product Description	23
4.1.1 Technical Features.....	23
4.1.2 Frame Shape.....	24
4.1.3 Degree of Protection.....	24
4.1.4 Output Shaft.....	25
4.1.5 Bearings.....	25
4.1.6 Cooling.....	25
Natural Convection.....	25
Surface Ventilation.....	25
Liquid Cooling	26
4.2 Product Identification	27
4.2.1 Type Code	27
4.2.2 Rating Plate.....	28
5 Transport and Storage.....	29
5.1 Transport (Shipping) Instructions.....	29
5.2 Instructions on Machine Transport.....	29
5.3 Product Storage.....	30
5.4 Storage Times.....	30
6 Assembly	33
6.1 Motor Assembly.....	33

Table of Contents

	Page
6.1.1 Flange Assembly.....	33
6.1.2 Foot Assembly.....	33
6.1.3 Attaching Transmission Elements.....	35
6.2 Connecting the Electric Supply	36
6.2.1 Safety.....	36
6.2.2 Plug Connectors.....	36
6.2.3 Fan Units	40
General.....	40
Plug Connector RLS0780 for 1-phase Fan Connection.....	41
Plug Connector RLS0782 for 3-phase Fan Connection.....	41
Terminal Box LEM-AB-XXXT-21-NPNN; XXX=140,192 for 1-phase Fan Connection	42
6.3 Connecting the Cooling Water Supply.....	42
7 Commissioning and Operation.....	45
7.1 Safety.....	45
7.2 Commissioning.....	45
7.3 Operation.....	46
8 Maintenance and Repair	47
8.1 Cleaning and Servicing	47
8.2 Service Repair, Maintenance and Spare Parts.....	49
9 Disassembly and Exchange	51
9.1 Tools Required	51
9.2 Exchanging the Motor.....	51
9.3 Preparing Storage	52
10 Environmental Protection and Disposal	53
11 Extension and Modification	55
11.1 Optional Accessories.....	55
11.1.1 Ready-made Connection Cables.....	55
11.1.2 Fan Units.....	55
11.1.3 Sealing Air Connection.....	56
12 Troubleshooting	59
12.1 Troubleshooting Procedure	59
13 Technical Data.....	61
14 Appendix.....	63
14.1 Declarations of Conformity.....	64
14.2 Terminal Box.....	66

Table of Contents

	Page
14.2.1 General.....	66
14.2.2 Terminal Box Type RZK3100.....	66
14.2.3 Terminal Boxes Type RKL1200, RKL1300.....	69
Index.....	73

[About this Documentation](#)

1 About this Documentation

1.1 Validity of this Documentation

This documentation is valid for Rexroth housing motors of the MSK series and must be observed by assemblers, operators, service engineers and facility operators.

1.2 Additional Documentation

Operate this product only, if you have the following documentation available. You must understand and observe this documentation.

	Title	Document type	Document number
	Rexroth IndraDyn S - Synchronous Motors MSK	Project Manual	Planning DOK-MOTOR*-MSK*****-PR----P
	Rexroth Indra Dyn S Synchronous Motors MSK for Hazardous Areas	Project Manual	Planning DOK-MOTOR*-MSK*EXGIIK3-PR----P
	Rexroth Connection Cables IndraDrive and IndraDyn	Selection Data	DOK-CONNEX-CABLE*INDRV-AU----P

Fig. 1-1: Additional documentation

1.3 Presentation of Information

Safety Instructions

The safety instructions in these operating instructions include signal words (danger, warning, caution, note) and a signal symbol (acc. to ANSI Z535.6-2006).

The signal word is intended to draw your attention to the safety instructions and describes the seriousness of the danger. The warning triangle with exclamation mark indicates the danger for persons.

DANGER

Non-compliance with this safety instructions **will** result in death or severe personal injury.

WARNING

Non-compliance with this safety instructions **can** result in death or severe personal injury.

CAUTION

Non-compliance with this safety instructions can result in moderate or minor personal injury.

NOTICE

Non-compliance with this safety instructions can result in material damage.

About this Documentation

Symbols

Symbol	Meaning
	Reference to supplementary documentation
	This note gives important information, which must be observed.
►	Single, independent action step
1. 2. 3.	Numbered action instructions: The numbers show that the action steps must be taken one after the other.
	Warning against dangerous electric voltage
	Warning against hot surfaces
	Warning against rotating machine parts
	Warning against overhead load
	Electrostatic sensitive devices
	Prohibition for persons with cardiac pacemaker
	Do not carry along metal parts or clocks
	Hammer scales are forbidden
	ATEX sign; explosion protection designation
	The UL Recognized Component Mark shows recognized component parts which are components of a bigger product or system.
	The letters C and E stand for "Conformité Européenne". The CE mark only shows that a product conforms with the respective EC guidelines. Conformity with the Low Voltage Directive 2006/95EC, EN 60034-1, EN 60034-5 is confirmed for MSK motors.
	Component prepared for use in systems for "integrated safety technology".

Fig. 1-2: Meaning of symbols

2 Safety Instructions

2.1 About this Chapter

Please observe the general safety instructions in this chapter and the safety-related guidelines and handling instructions in this manual. This will prevent personal hazards, material damage and errors.



This manual must be stored by the user during the whole product lifetime and passed on when selling.

2.2 Appropriate Use

Prerequisites for appropriate and safe use of the motors are proper transport and storage, correct assembly and connection and careful maintenance and operation.

The motors have been designed for installation in industrial machinery. The motors comply with the following standards and directives.

Standards

EN 60034-1	Rating and performance
EN 60034-5	Degree of protection

Directives

2006/95/EC	Low Voltage Directive
------------	-----------------------

The machine manufacturer must evaluate the electric and mechanic safety as well as environmental influences in the assembled state of the machine according to the Machine Directive 2006/42/EC and DIN EN 60204-1 (safety of machines).

The electric installation must comply with the protection requirements of the EMC Directive 2004/108/EC. The proper installation of the system (for instance physical separation of signal and power cables, use of shielded cables ...) is the responsibility of the plant manufacturer. The converter manufacturer's EMC instructions must be observed.

The machine may not be commissioned before conformity with these directives has been determined.

2.3 Inappropriate Use

Any use of the MSK motors outside of the specified fields of application or under operating conditions and technical data other than those specified in this documentation is considered to be "inappropriate use".

Unless explicitly provided for this purpose, the motors may not be used in explosion-hazardous areas (ATEX) (see housing design -NSNN).

Direct operation on the three-phase network is forbidden.

2.4 Personnel Qualification

For the purpose of this manual, qualified personnel means persons who are familiar with transporting, installing, mounting, commissioning and operating the components of the electrical drive and control system and the associated hazards and have an appropriate qualification for their job.

Safety Instructions

All persons working on, with or in the vicinity of an electrical system must be informed of the relevant safety requirements, safety guidelines and internal instructions (EN 50110-1).

2.5 General Safety Instructions

Do not install or operate motors or components of the electric drive and control system before you have not carefully read all delivered documents.

Please observe the particular applicable national, local and system-specific regulations, the safety instructions in the documentation and the warning and informative labels on the motors.

Improper use of the motors and failure to follow the safety instructions in this document may result in material damage, personal injury, electric shock or, in extreme cases, to death!

For damage due to non-compliance with the safety instructions, Bosch Rexroth does not assume any liability.

Applications for functional safety are only allowed if the motors have the SI sign on the rating plate.

2.6 Product and Technology-dependent Safety Instructions

2.6.1 Protection against Electrical Voltage

Work required on the electric system may only be carried out by skilled electricians. Tools for electricians (VDE tools) are absolutely necessary.

Prior to commencing the work:

1. Isolate.
2. Protect the system or plant against restart.
3. Ensure de-energization.
4. Ground and short-circuit.
5. Cover or shield any adjacent live parts.

After completion of the work, unmake the measures in reverse order.

During operation, dangerous voltages occur! Danger! Risk of injury due to electric shock!

- Before switching on, establish the fixed connection of the protective conductor to all electric components according to the interconnection diagram.
- Operation, even for short-term measuring and testing purposes, is only permitted with the protective conductor securely connected to the component points provided.

2.6.2 Protection against Mechanical Hazards

Dangerous movements! Danger to life, risk of injury, severe personal injury or material damage!

- Do not stay within the area of motion of the machine. Prevent persons from accidentally entering the danger zone.
- Make vertical axes safe against falling or declining after switching off the motor, e.g., by
 - locking the vertical axis mechanically,
 - providing an external braking / catching / clamping device, or

Safety Instructions

- ensuring sufficient equilibration of the vertical axis.

Only using the serially delivered **motor holding brake** or an external holding brake activated by the drive controller is **not suitable for personal protection!**

Rotating parts! Danger to life, risk of injury, severe personal injury or material damage!

- Secure key and/or transmission elements against ejection.
- Install covers on dangerous rotating machine parts before start-up.

2.6.3 Protection against Magnetic and Electromagnetic Fields

Magnetic and electromagnetic fields are created in the direct environment of live conductors or permanent magnets of electric motors and can be a great danger for persons.

Strong magnetic and electromagnetic fields pose a health hazard for persons with heart pacemakers, metallic implants and hearing aids in the direct environment of motor components!

- Persons with heart pacemakers and metallic implants are not allowed to approach or handle these motor components.

Crushing hazard of fingers and hands due to strong attractive forces of the magnets!

- Handle only with protective gloves.

Risk of destruction of sensitive parts!

- Keep watches, credit cards, check cards and identity cards with magnetic strips as well as all ferromagnetic metallic parts such as iron, nickel and cobalt away from the permanent magnets.

2.6.4 Protection against Burns

Risk of burns by hot surfaces!

- Avoid contact with hot motor surfaces. **Temperatures may rise to over 70 °C.**
- Allow the motors to cool down long enough before touching them.
- Temperature-sensitive components may not come into contact with the motor surface. Ensure appropriate mounting distance of connection cables and other components.

3 Scope of Delivery

The scope of delivery of an IndraDyn housing motor contains:

- Motor in original package
- Additional rating plate
- Operating instructions with safety instructions
- Optional connecting accessories for motors with terminal box
- Protective covers for output shaft, plug connections and coolant connections of water-cooled motors.
- Accompanying papers

On delivery, immediately verify whether the delivered goods are those specified on the delivery note. The forwarder must be promptly informed of any damage on the packaging and goods, which is detected on delivery. It is forbidden to use damaged products.

[About this Product](#)

4 About this Product

4.1 Product Description

4.1.1 Technical Features

The motors of the MSK series are three-phase synchronous motors which are energized by a permanent magnet and are suitable for operation on converters or inverters of Bosch Rexroth.

Product	Three-phase synchronous motor
Manufacturer	Bosch Rexroth Electric Drives and Controls GmbH Buergermeister-Dr.-Nebel-Strasse 2 97816 Lohr am Main / Germany
Type	MSK030, -040, -043, -050, -060, -061, -070, -071, -075, -076, -100, -101, -103, -131, -133
Listing acc. to UL standard (UL)	UL 1004, Fifth Edition
Listing acc. to CSA standard (UL)	Canadian National Standard(s) C22.2 No. 100-04
UL files (UL)	E 335445
Ambient temperature in operation	0 ... 40 °C
Motor design	B5 (EN 60034-7) B35 (EN 60034-7)
Degree of protection	IP65 (EN 60034-5)
Vibration severity grade	Level A (EN 60034-14)
Concentricity, run-out and alignment	Tolerance N (IEC 60072-1) for encoders S1, M1, S3, M3 Tolerance R (IEC 60072-1) for encoders S2, M2
Flange	acc. to DIN 42948
Shaft end	Cylindric (DIN 748 part 3), keyway optional, centering hole (DIN 332 part 2)
Installation altitude	0 ... 1,000 m
Sound pressure level	< 75 dB(A)
Insulation class	155 (EN 60034-1)
Balancing	Full-key balancing
Electrical connection	Flange socket for power and encoder Terminal box
Encoder system	S1 (optical, Singleturn Hiperface, 128 signal periods) S2 (optical, Singleturn EnDat 2.1, 2048 signal periods) S3 (optical, Singleturn Hiperface, 16 signal periods) M1 (optical, Multiturn Hiperface, 128 signal periods) M2 (optical, Multiturn EnDat 2.1, 2048 signal periods) M3 (optical, Multiturn Hiperface, 16 signal periods)
Motor holding brake (optional)	Principle: electrically released U _N 24V DC (±10%)



Special versions may deviate from the details specified in these operating instructions. In this case, the related supplementary documentation must be requested.

About this Product

4.1.2 Frame Shape

Motor design B05				B35
IM B5	IM V1	IM V3	IM B3	
Flange attachment on the drive side of the flange	Flange attachment on the drive side of the flange, drive side facing down	Flange attachment on the drive side of the flange, drive side facing up	Foot assembly, feet at the bottom	

Fig.4-1: Permissible types of installation according to EN 60034-7

4.1.3 Degree of Protection

Motor area	Degree of Protection	Remark
Motor housing, output shaft, motor connector with professional assembly in connected state	IP65	Standard design
Motor housing, output shaft, motor connector with professional assembly in connected state and use of sealing air	IP67	Sealing air accessories
Fan motor and flange socket in connected state	IP65	Fan unit accessories
Fan grille	IP24	Fan unit accessories

- ① Output shaft with shaft sealing ring
- ② ③ Flange socket for power and encoder connection(can be optionally retrofitted for sealing air)
- ④ Fan motor with flange socket
- ⑤ Fan grille

Fig.4-2: IP protection areas of MSK motors

[About this Product](#)

4.1.4 Output Shaft

Centering hole, according to DIN 332 Part 2, Edition 05.83	MSK														
	030	040	043	050	060	061	070	071	075	076	100	101	103	131	133
DS M3	■														
DS M5		■	■												
DS M6				■		■									
DS M8					■					■					
DS M10							■	■	■		■				
DS M12												■	■		
DS M16													■	■	

Fig.4-3: Centering hole

Corresponding key according to DIN 6885-A (is not included in scope of delivery)	MSK														
	030	040	043	050	060	061	070	071	075	076	100	101	103	131	133
3x3x16	■														
5x5x20		■	■												
6x6x32				■		■									
8x7x40					■					■					
10x8x45							■	■	■		■				
10x8x70												■			
14x9x80														■	

Fig.4-4: Keys

4.1.5 Bearings

The motors are equipped with permanently greased deep-groove ball bearings. The fixed bearing is on the B-side. The nominal bearing service life L_{10h} is 30,000 h, considering the shaft and bearing loads specified in the project planning manual.

4.1.6 Cooling

Natural Convection

Nominal data is reached at ambient temperatures of up to 40 °C. The installation situation must be selected such that sufficient heat dissipation is ensured. Unhindered vertical convection must be ensured by a sufficient distance of 100 mm to neighboring components on the lateral surfaces. Soiling of the motor surface reduces heat dissipation, see [chapter 12 "Troubleshooting" on page 59](#).

Surface Ventilation

Cooling is realized by external radial (LEM-RB) or axial (LEM-AB) fan units. The different voltage ranges and the additional instructions in the project planning manual must be observed.


 DOK-MOTOR*-MSK*****-PR----P, "Rexroth IndraDyn S Synchronous Motors MSK".

Dirt and contaminants can reduce the flow rate of the fans and result in a thermal overload of the motors. Only use clean ambient air for cooling. Heated air may not be sucked in again.

About this Product

It is explicitly prohibited to use the fan under the following conditions:

- Delivery of air which contains abrasive particles
- Delivery of air which has a strongly corroding effect, e.g., salt mist
- Delivery of air which contains a high dust load, e.g., extraction of saw dust
- Delivery of combustible gases/particles
- Using fan units as safety related part or for assumption of safety related functions



- | | |
|---|------------------|
| ① | Machine |
| ② | Air outlet space |
| ③ | Air inlet space |

Fig.4-5: Fan units Installation space, minimum distance

When designing the machine, take the minimum distance of the air supply ③ into account.

Liquid Cooling

Liquid cooled motors are operated in a closed coolant system with heat exchanger. The coolant flow direction can be selected as desired.

Anti-corrosion agents must be added to the coolant system. Please observe the information provided in the Project Planning Manual.

DOK-MOTOR*-MSK*****-PR----P, "Rexroth IndraDyn S Synchronous Motors MSK".

About this Product

4.2 Product Identification

4.2.1 Type Code




Fig.4-6: Type code overview

About this Product

4.2.2 Rating Plate




Fig.4-7: Type plate MSK

5 Transport and Storage

5.1 Transport (Shipping) Instructions

The motors must be transported in their original package taking classes 2K2, 2B1, 2C2, 2S2, 2M1 specified acc. to DIN EN 60721-3-2 into account.

Please observe the following classification limitations:

- Transport temperature range -20 ... +80 °C
- Relative air humidity max. 75% (at +30 °C)
- No occurrence of salt mist



Before transport, discharge the liquid coolant from liquid-cooled motors to avoid frost damage.

5.2 Instructions on Machine Transport

NOTICE

Never touch the connection points of electrostatic sensitive devices!



Installed components (e.g., KTY84, encoder) may contain electrostatic sensitive devices (ESD).


- ▶ Observe ESD safety measures.

WARNING

Risk of injury and material damage due to improper handling during transport!



- ▶ Only use hoisting gear suited for the weight of the motors. Use lifting sling belts or lifting eye bolts. Secure the lifting eye bolts before use.
- ▶ Never walk under hanging loads.
- ▶ Do not lift the motor on the shaft or on the optional fan housing.
- ▶ Use suitable protective equipment and protective clothing during transport, and wear safety shoes.



① Eye bolts (check firm seating before use)

Fig.5-1: Lifting and transporting motors

- ▶ Before transporting the motor, determine the weight of the motor. For more details about motor weight, please refer to the rating plate or the Project Planning Manual (Technical Data).

Transport and Storage

- ▶ Adjust the carrying capacity of the lifting device to the motor weight.
- ▶ If provided by the manufacturer, all lifting eye bolts must be used and tightened before use.
- ▶ Avoid increased transport vibrations.
- ▶ Remove any existing transport locks prior to commissioning and keep them

5.3 Product Storage

Store the motors in their original package at a dry, dust free, vibration free and light protected place without direct solar radiation. Please observe classes 1K2, 1B1, 1C1,1S1,1M2 specified for storage acc. to DIN EN 60721-3-2.

Please observe the following classification limitations:

- Storage temperature -20 ... +60 °C
- Relative air humidity 5 ... 95 %
- Absolute air humidity 1 ... 29 g/m³
- No condensation
- No ice formation/freezing
- No occurrence of salt mist

NOTICE
Damage due to moisture and humidity!

- ▶ Use coverings to protect the products from moisture.
- ▶ Store them only in rainproof and dry rooms.



Before storage, discharge the liquid coolant from liquid-cooled motors to avoid frost damage.

5.4 Storage Times

Additional measures must be taken on commissioning to preserve proper functioning – irrespective of the storage time which may be longer than the warranty period of our products. However, this does not involve any additional warranty claims.

Motors

Bearing time / months			Measures for commissioning
> 1	> 12	> 60	
■	■	■	Visual inspection of all parts to be damage-free
■	■	■	Resurface the holding brake
	■	■	Check the electric contacts to verify that they are free from corrosion
	■	■	Let the motor run in without load for one hour at 800 ... 1000 rpm
	■	■	Measure insulation resistance. Dry the winding at a value of < 1kOhm per volt rated voltage.

Transport and Storage

Bearing time / months			Measures for commissioning
> 1	> 12	> 60	
		■	Exchange bearings
		■	Exchange encoders

Fig.5-2: Measures before commissioning motors that have been stored over a prolonged period of time

Cables and Connectors

Bearing time / months			Measures for commissioning
> 1	> 12	> 60	
■	■	■	Visual inspection of all parts to be damage-free
	■	■	Check the electric contacts to verify that they are free from corrosion
		■	Visually inspect the cable jacket. Do not use the cable if you detect any abnormalities (squeezed or kinked spots, color deviations, ...).

Fig.5-3: Measure before commissioning cables and connectors that have been stored over a prolonged period of time

6 Assembly

6.1 Motor Assembly

6.1.1 Flange Assembly

NOTICE

Motor damage due to ingress of liquids!

Liquid which exists over a longer period on the shaft sealing ring of the output shaft can ingress into the motor and cause damage.

- ▶ Ensure that liquid cannot be present at the output shaft.
- ▶ Do not mount any open gearboxes (gearboxes that are not hermetically sealed).

For details on mounting holes, please refer to the Project Planning Manual.

 DOK-MOTOR*-MSK*****-PR----P, "Rexroth IndraDyn S Synchronous Motors MSK". Use all motor mounting holes to mount the motor safely to the machine.

- ▶ If coupling is direct, ensure that the support is plane and the orientation is precise.
- ▶ Avoid pinching or jamming the centering collar on the motor side.
- ▶ Avoid damage to the insertion fitting on the system side.
- ▶ Use the following screws and washers for flange assembly.

Mounting screws for IndraDyn motors

Hole ø [mm]	Screw 8.8 DIN EN ISO 4762 DIN EN ISO 4014	Tightening torque M _A [Nm] at μ _K = 0.12	washer DIN EN ISO 28738
4,5	M4 × 20	3	-
6,6	M6 × 20	10.1	-
9	M8 × 20	24.6	Yes
11	M10 × 30	48	Yes
14	M12 × 40	84	Yes
18	M16 × 35	206	Yes

Fig.6-1: Tightening torque of mounting screws

6.1.2 Foot Assembly

Before attaching the motors according to the foot assembly method, observe the clearance from the center of the motor shaft to the bottom edge of the foot specified in the particular motor dimension drawing. Compare this clearance with the connection clearance actually present on the machine.



The mounting holes and clearances correspond to the general tolerance according to DIN ISO 2768-1m (tolerance class m).

Before attaching the motor to the machine, align the motor such that the center line of the motor shaft is flush with the center line of the connection shaft.

If attaching the motors according to the foot assembly method, proceed as follows:

Assembly

1. Dismount the lower lateral air baffles to have free access to the mounting holes.
2. Align the motor such that the center line of the motor shaft is flush with the center line of the connection shaft of the machine. Support the motor on sheet steel strips when aligning it.
3. Firmly connect the motor to the machine.


Fastening screws for foot assembly of IndraDyn motors.

Motor frame size	Hole ø [mm]	Screw 8.8 DIN EN ISO 4762 DIN EN ISO 4014	Tightening torque $M_A[\text{Nm}]$ at $\mu_K=0.12$	Washer DIN EN ISO ...
133	11	M10 x ...	48	28738

Fig.6-2: Fastening screws (foot mounting) tightening torque

4. Reattach the air baffles to the motor.

In contrast to flange assembly, radial forces may only be effective in a direction perpendicular to the mounting surface ($\pm 15^\circ$) if foot assembly is selected. The transmission of forces in other effective directions is not allowed.



① Mounting feet
Fig.6-3: Force direction at foot mounting



Please note the following in case of foot assembly ...

- Forces which are transmitted by a gear and have an effect on the motor feet are not allowed.
Forces taking effect via the gear shaft must be supported against the gear.
- Incorrect installation situations give rise to forces which may cause short-term damage to the motors.
- If necessary, consider "flange assembly" as an alternative.

6.1.3 Attaching Transmission Elements

Fit and pull off the transmission elements such as pulleys and couplings only with suitable equipment; heat them, if necessary.

- ▶ Avoid unallowed belt tensions. Please consider the allowed radial and axial forces in the project planning manuals.
- ▶ The balancing state of transmission elements must comply with the full-key balancing of the motors.

NOTICE

Motor damage due to strikes onto the motor shaft



- ▶ Do not strike the shaft end and do not exceed the allowed axial and radial forces of the motor.

Fitting




Fig. 6-4: Fitting the transmission element

- ▶ Use the centering hole for fitting transmission elements. For details on centering holes, please refer to the Project Planning Manual.

- ▶ DOK-MOTOR*-MSK*****-PR---P, "Rexroth IndraDyn S Synchronous Motors MSK". Heat the output element, if necessary.

Assembly

6.2 Connecting the Electric Supply

6.2.1 Safety

⚠ WARNING

Danger! Electric voltage! Operations in the vicinity of live parts are extremely dangerous.



Work required on the electric system may only be carried out by skilled electricians. Tools for electricians (VDE tools) are absolutely necessary.

Prior to commencing work:

1. Isolate (even auxiliary circuits).
2. Protect the system or plant against restart.
3. Ensure de-energization.
4. Ground and short-circuit.
5. Cover or shield any adjacent live parts.

⚠ WARNING

High electrical voltage! Danger to life, risk of injury due to electric shock.



While the rotor is rotating, motors with permanent magnet excitation create a voltage > 60 V at the motor connections.

- ▶ Any work may only be carried out while the motor is at standstill.
- ▶ Never connect or disconnect plug connectors under load!

NOTICE

Never touch the connection points of electrostatic sensitive devices!



Installed components (e.g., KTY84, encoder) may contain electrostatic sensitive devices (ESD).

- ▶ Observe ESD safety measures.

6.2.2 Plug Connectors

When using the flange socket, please ensure the following:

- Use ready-made cables of Rexroth, see documentation DOK-CONNEX-CABLE*INDRV-AU---P, "Rexroth Connection Cables IndraDrive and IndraDyn".
- Observe the circuit diagrams specified in the Project Planning Manual, see DOK-MOTOR*-MSK*****-PR---P, "Rexroth IndraDyn S Synchronous Motors MSK".
- The connections must be established such that a permanent safe electrical connection is ensured.
- Establish a safe protective conductor connection.
- Only use flange sockets which are free from dirt, foreign bodies and humidity.

Assembly


- Completely tighten the flange sockets in screw design. The vibration O-ring may no longer be visible.
- Connect or disconnect plug connections only in de-energized, dry and clean state.
- Protect the flange sockets from external force effect.

Connection diagram








The following connection diagram shows a possible connection. The installation regulations applicable at the place of machine installation must be complied with.

Assembly



- | | |
|---|---|
| ① | Motor housing |
| ② | Power flange socket |
| ③ | Encoder flange socket |
| ④ | Equipotential bonding connection at the motor (only available on ATEX motors) |
| ⑤ | Equipotential bonding connection at the machine (necessary for ATEX motors) |
| ⑥ | Rexroth drive controller |
- Fig.6-5: Flange socket connection diagram*


Connector size	Pole pattern	Flange socket	Remark
M23		U1 A1 W1 A2 V1 A3 PE 5 MotTemp+ 6 MotTemp- 7 +24VBr 8 0VBr 9 n.c.	RLS1100 ¹⁾ RLS1103
M40		U1 A1 W1 A2 V1 A3 PE 5 MotTemp+ 6 MotTemp- 7 +24VBr 8 0VBr 9 n.c.	RLS1200 ¹⁾ RLS1203
M58		U1 A1 W1 A2 V1 A3 PE 5 MotTemp+ 6 MotTemp- 7 +24VBr 8 0VBr 9 n.c.	RLS1300
M23		1 VCC_Encoder 2 GND_Encoder 3 A+ 4 A- 5 B+ 6 B- 7 Enc_Data+ 8 Enc_Data- 9 Enc_CLK+ 10 Enc_CLK-	RGS1000 ¹⁾ RGS1003
M23		1 A+ 11 B+ 2 A- 12 B- 3 n.c. 13 n.c. 4 n.c. 14 ENncData+ 5 VCC_Encoder 15 n.c. 6 n.c. 16 n.c. 7 GND_Encoder 17 EncData- 8 Enc_CLK+ 9 Enc_CLK- 10 VCC_Encoder	RGS1010

1) Rotary flange socket

Fig.6-6: Flange socket pole patterns

The orientation of the flange socket is adjustable. To change the orientation, screw a coupling completely to the flange socket. Then move the flange socket to the desired position, using the coupling. The possible adjustments are shown in the following figure.

Assembly

Fig.6-7: *Rotary flange socket adjustment ranges*

Flange socket	Maximum turning torque ¹⁾ [Nm]
RGS1000	
RGS1010	12
RLS1100	
RLS1200	18

1) Maximum torque for changing the orientation of the flange sockets
Fig.6-8: Flange socket turning torques

- Never exceed the specified turning torques.
- Do not change the connector output direction more than 10 times.

6.2.3 Fan Units

General


MSK motors can be optionally operated with fan units. Please observe the following connection instructions:

- Connect the fan unit according to the connection voltage on the rating plate.
- Establish a safe protective conductor connection.
- Only use suitable installation material.

For technical data, please refer to DOK-MOTOR*-MSK*****-PR----P, "Rexroth IndraDyn S Synchronous Motors MSK".

Motors with axial fan unit
When motors are provided with an axial fan unit, the flange socket for encoder connection is covered by the fan hood.

- Unscrew the cover plate from the fan housing to be able to connect the encoder plug connector.
- Re-attach the cover plate after completed connection (shock protection).



1 Connection for encoder flange socket
Fig. 6-9: Encoder connector cover plate

Plug Connector RLS0780 for 1-phase Fan Connection




Fig. 6-10: Pin assignment, line connector, LEM

LEM fan units in design "T" with integrated thermal protection. The fan units "T" do **not** need any circuit with external motor protection.

- ▶ The delivered cable fitting can be used for cable diameters 7 ... 10 mm.

Plug Connector RLS0782 for 3-phase Fan Connection




Fig. 6-11: Pin assignment, line connector, LEM

Provide LEM fan units in design "N" with external motor protection (not included in scope of delivery).

- ▶ The delivered cable fitting can be used for cable diameters 7 ... 10 mm.

Assembly

Terminal Box LEM-AB-XXXT-21-NPNN; XXX=140,192 for 1-phase Fan Connection




Fig.6-12: Fan cable connection

LEM fan units in design "T" with integrated thermal protection. The fan units "T" do **not** need any circuit with external motor protection switch.

- Use a cable gland M16 x 1.5 according to the cable diameter. The cable gland is not included in the scope of delivery.

6.3 Connecting the Cooling Water Supply

Coolant connection is necessary for MSK-...-FN motors.

⚠ WARNING

Danger of injury due to improper handling of conductors which are under pressure!

- Observe the manufacturers' operating instructions and specifications referring to the cooling system.
- Wear suitable protective equipment (e.g. safety goggles, protective gloves, safety shoes).
- Remove spilled liquid from the floor immediately to prevent the risk of falling!
- Release pressure and discharge medium before dismounting the lines.
- Do not try to strip, open or cut lines that are under load.



The inlet (IN) and outlet (OUT) can be assigned as desired. The assignment does not have any effect on the performance data of the motor.

The connection threads on the motor are covered with protective plugs at the factory. These protective plugs may only be removed immediately before screwing in the connections to prevent dirt from entering into the cooling system.

Connection thread for coolant ducts

Frame size	Connection:	Screw-in depth [mm]	Tightening torque [Nm]
MSK071	Pipe thread ISO 228 – G 1/8	8	14 ... 15
MSK075	Pipe thread ISO 228 – G 1/8	8	14 ... 15
MSK101	Pipe thread ISO 228 – G 1/8	9	14 ... 15
MSK133	Pipe thread ISO 228 – G 1/4	14	18 ... 20

Fig.6-13: Coolant port, allowed tightening torques and screw-in depths

NOTICE

The coolant port threads on the motor may be destroyed by incorrect tightening torques!

The allowed motor connection tightening torque may not be exceeded! If the tightening torque or screw-in depth is exceeded, the motor may be damaged irreversibly.

The motor-sided coolant ports are provided for coolant port connections with axial seal.

Bosch Rexroth therefore recommends to use screw connections which already contain an O-ring for sealing the screw connection in axial direction.

For example, seals consisting of hemp, teflon tape or cone-shaped screw connections are not considered to be suitable because this type of seal may stress the connection thread on the motor to an unreasonably high extent and/or damage it permanently.



The machine manufacturer is responsible for ensuring that the coolant port is tight and for verifying and accepting this tightness after the motor has been installed.

Moreover, the maintenance schedule of the machine should provide for a regular check of the proper state of the cooling port.

The maximum input pressure of the motors is **6 bar** (3 bar for motors produced prior to 2010-01-01, 10W01).

- ▶ Ensure that the cooling water meets the requirements; cf. Project Planning Manual DOK-MOTOR*-MSK*****-PR---P, "Rexroth IndraDyn S Synchronous Motors MSK".

7 Commissioning and Operation

7.1 Safety

 **WARNING**

High electrical voltage! Danger to life, risk of injury due to electric shock.



Live parts are dangerous.

- ▶ Do not open any covers or flange sockets during operation.
- ▶ Never connect or disconnect plug connectors under load!

 **WARNING**

Risk of injury due to rotating motor shaft!



- ▶ Do not remove any covers, machine parts or protection devices during operation.
- ▶ Do not enter the range of movement of the machine. Prevent persons from entering this area, e.g., by means of
 - Safety fence, safety guards, protective covers
 - Optical sensors

 **CAUTION**

Thermal danger due to hot surfaces with temperatures over 70 °C during operation



- ▶ Do not touch hot motor surfaces.

- ▶ Install protection against contact, if necessary.

- ▶ Make sure that no temperature-sensitive components (cables, electronic components, ...) touch hot surfaces.

7.2 Commissioning

MSK motors can only be commissioned with other components (drive controller, control unit).

Prior to commissioning

Prior to commissioning, ensure that the following requirements are met.

- Storage time of the motor. Depending on the storage time, take measures to ensure safe operation. Run in bearings, resurface the holding brake, See [fig. 5-2 "Measures before commissioning motors that have been stored over a prolonged period of time" on page 30](#).
- Ensure that all flange socket are correctly connected and protected against coming loose.
- Ensure that a holding brake voltage of 24 V ±10% is applied to the motor. If necessary, adjust the voltage.
- Check the proper function of the holding brake.
- Ensure that the motor and all participating components of the drive are undamaged.
- Ensure that keys are protected against ejection.

Commissioning

For details on the commissioning order, please refer to the respective documentation of the drive controller or firmware description.

Commissioning and Operation

Please observe the general safety instructions on the protection against hazardous movements [chapter 2.6.2 "Protection against Mechanical Hazards" on page 18](#).

7.3 Operation

During operation, keep the ambient and operation conditions and technical data specified in the project planning manual.

Checks during operation:

- ▶ Pay attention to exceptional noise.
- ▶ Pay attention to increased vibrations.
- ▶ Check the motor and fan units for cleanliness.
- ▶ Check the cooling water connections for tightness.
- ▶ Check the monitoring devices and diagnostic / error messages of the controllers.

Decommission the drive when deviations from normal operation exist. For further procedure refer to [chapter 12 "Troubleshooting" on page 59](#).

8 Maintenance and Repair

8.1 Cleaning and Servicing

 **WARNING**

Danger! Electric voltage! Operations in the vicinity of live parts are extremely dangerous.



Work required on the electric system may only be carried out by skilled electricians. Tools for electricians (VDE tools) are absolutely necessary.

Prior to commencing work:

1. Isolate (even auxiliary circuits).
2. Protect the system or plant against restart.
3. Ensure de-energization.
4. Ground and short-circuit.
5. Cover or shield any adjacent live parts.

 **WARNING**

Maintenance work during ongoing operation may result in personal injury and material damage!



- ▶ Do not carry out any maintenance measures while the machine is running.
- ▶ During maintenance work, protect the system against restarting and unauthorized use.

 **CAUTION**

Hot surfaces with temperatures over 70 °C may cause burns!



- ▶ Allow the motors to cool down prior to commencing work.
- ▶ Wear safety gloves.
- ▶ Do not work on hot surfaces.

Motors

Excessive dirt, dust or chips may adversely affect the functionality of the motors and, in extreme cases, even cause a failure of the motors. Clean the cooling fins of the motors at regular intervals (after one year at the latest) to reach a sufficiently high heat emission surface. If the cooling fins are partially covered with dirt, sufficient heat dissipation via the ambient air is no longer ensured.

Connection cable

 **WARNING**

Contact with live parts may cause death by electrocution!



- ▶ Change damaged connection cables and decommission the plant immediately.
- ▶ Do not repair any connection lines provisionally.

- Check connection cables for damage at regular intervals and replace them, if necessary.

Maintenance and Repair

- Check any optional energy management chains (drag chains) for defects.
- Check the protective conductor connection for proper condition and firm seating at regular intervals and replace it, if necessary.

8.2 Service Repair, Maintenance and Spare Parts

Wearing parts are reliably and professionally repaired and replaced by the Bosch Rexroth Service in shopfloor-oriented quality.

The service lives of motor components, such as seals and bearings, may vary depending on the operating conditions, such as operation mode, speed, vibration and shock load, and frequent reverse mode.

We recommend to change the bearing after 30,000 operating hours. Shorter replacement intervals may be necessary; cf. checks during operation [chapter 7.3 "Operation" on page 46](#).

We recommend regular visual inspections on shaft sealing rings. Depending on operating conditions, signs of wear may appear after 5,000 operating hours. If necessary, replace the shaft sealing rings.



We recommend to have these repairs made by Bosch Rexroth Service.

The Bosch Rexroth service helpdesk at our headquarters in Lohr, Germany and our worldwide service provide You can contact us **24/7**.

Phone: **+49 (0) 9352 40 50 60**

Fax **+49 (0) 9352 18 49 41**

Email: **service.svc@boschrexroth.de**

Internet: **<http://www.boschrexroth.com>**

Preparing information

For quick and efficient help, please have the following information ready:

- Detailed description of the fault and the circumstances
- Information on the rating plate of the products in question, particularly type codes and serial numbers
- Your contact data (phone number, fax number, e-mail address)

9 Disassembly and Exchange

9.1 Tools Required

NOTICE


Motor damage due to strikes onto the motor shaft



- ▶ Do not strike the shaft end and do not exceed the allowed axial and radial forces of the motor.

Use suitable tools when disassembling transmission elements.

Pulling off



① Shim

Fig.9-1: Pulling off the transmission element

Use tools suitable for pulling off. Use a shim to protect the shaft end when using pulling-off tools. Heat the output element, if necessary.

9.2 Exchanging the Motor

⚠ WARNING

Lethal electric shock by live parts with more than 50 V!

The supply unit may only be replaced by qualified personnel which have been trained to perform the work on or with electrical devices.



The motor should be replaced by a motor of identical type. This is the only way to ensure that all parameterizations can remain unchanged. Moreover, repeated acceptance within the scope of the "Integrated switching technology" function is not required.

1. If necessary, note down the previous absolute value
2. Open the main switch
3. Ensure that the main switch cannot be accidentally switched on again
4. Disconnection plug connections



When exchanging the motor, close open plug sides of power connections with protection caps if moistening with coolant/lubricant or soiling must be expected (allowed soiling degree according to EN 50178: 2).

5. Exchange the motor



Observe the machine manufacturer's instructions when exchanging the motor mechanically.

Disassembly and Exchange

6. Re-establish the plug connections
7. Re-establish the dimensional reference

⚠ WARNING

Risk of accidents due to unintentional axis movements!

If servo axes are provided with an indirect position measuring system via the motor encoder, the dimensional reference is lost after motor replacement!

For this reason, the reference to the machine coordinate system must be re-established.

9.3 Preparing Storage

Before motors are stored, the protection covers on flange socket, shaft and input openings for cooling water in case of liquid-cooled motors which were attached on delivery must be re-attached.

When motors are liquid-cooled, completely discharge the coolant from the cooling tubes (e.g., via purging the coolant holes with pressure air). This will prevent frost damage at storage temperatures lower than 0 °C.

10 Environmental Protection and Disposal

Production processes	The products are made in energy- and resource-optimized production processes which allow re-using and recycling the resulting waste. We regularly try to replace pollutant-loaded raw materials and supplies by more environment-friendly alternatives.
No release of hazardous substances	Our products do not contain any hazardous substances which may be released in case of appropriate use. Normally, our products will not have any negative influences on the environment.
Significant components	Basically, our motors consist of the following components: steel, aluminum, copper, brass, permanent magnets (rare earth metal), electronic components.
Return of products	<p>Our products can be returned to us for disposal free of charge. However, this requires that the products be free from oil, grease or other dirt.</p> <p>Furthermore, the products returned for disposal may not contain any undue foreign material or foreign components.</p> <p>Deliver the products "free domicile" to the following address:</p> <p>Bosch Rexroth AG Electric Drives and Controls Buergermeister-Dr.-Nebel-Strasse 2 97816 Lohr am Main, Germany</p>
Permanent magnets	Permanent magnets present a serious danger during disposal.
<hr/> <div style="display: flex; justify-content: space-between;">  WARNING Danger due to permanent magnets! </div> <div style="display: flex; align-items: center;">  <ul style="list-style-type: none"> ▶ Health hazard for persons with heart pacemakers, metallic implants and hearing aids in direct environment of permanent magnets.  <ul style="list-style-type: none"> ▶ Crushing hazard of fingers and hand due to heavy attractive forces of the magnets.  <ul style="list-style-type: none"> ▶ Risk of destruction of sensitive parts such as watches, credit cards, </div> <hr/>	
Packaging	<p>Packaging materials consist of cardboard, wood and polystyrene and can be recycled anywhere without any problem.</p> <p>For ecological reasons, please refrain from returning the empty packages to us.</p>
Batteries and Accumulators	<p>Batteries and accumulators can be labeled with this symbol.</p> <div style="text-align: center;">  <p>The symbol indicating "separate collection" for all batteries and accumulators is the crossed-out wheeled bin.</p> </div> <p>End users in the EU are legally bound to return used batteries. Outside the validity of the EU Directive 2006/66/EC, the particularly applicable regulations must be followed.</p> <p>Used batteries can contain hazardous substances which can harm the environment or people's health when improperly stored or disposed of.</p>

Environmental Protection and Disposal

- After use, the batteries or accumulators contained in Rexroth products must be properly disposed of according to the country-specific collection systems.
- Recycling** Most of the products can be recycled due to their high content of metal. In order to recycle the metal in the best possible way, the products must be disassembled into individual assemblies.
- Metals contained in electric and electronic assemblies can also be recycled by means of special separation processes.
- Plastic parts of the products may contain flame retardants. These plastic parts are labeled according to EN ISO 1043. They have to be recycled separately or disposed of according to the applicable legal provisions.

Extension and Modification

11 Extension and Modification

11.1 Optional Accessories

11.1.1 Ready-made Connection Cables

	Title	Document type	Document number
	Rexroth Connection Cables IndraDrive and IndraDyn	Selection data	DOK-CONNEX-CABLE*INDRV-AU----P

Fig. 11-1: Additional documentation

11.1.2 Fan Units

	Title	Document type	Document number
	Rexroth IndraDyn S - Synchronous Motors MSK	Project Planning Manual	DOK-MOTOR*-MSK*****-PR----P
	Rexroth LEM-AB-116T, LEM-AB-140T	Package Insert	DOK-MOTORx-LEMAB1XXTxx-IS01-D0-P
	Rexroth LEM-AB-192T	Package Insert	DOK-MOTORx-LEMAB192Txx-IS01-D0-P
	Rexroth LEM-RB-116T, LEM-AB-140T	Package Insert	DOK-MOTORx-LEMRB1XXTxx-IS01-D0-P
	Rexroth LEM-RB-192T	Package Insert	DOK-MOTORx-LEMRB192Txx-IS01-D0-P

Fig. 11-2: Additional documentation

Extension and Modification

11.1.3 Sealing Air Connection

In order to use sealing air in IndraDyn S motors, the system must have a compressed air connection. The required compressed air preparation system and the hoses for the compressed air must be provided by the customer.

Designation	Symbol	Unit	Value
Working pressure	o	bar	0,1 ± 0,05
Max. relative air humidity	φ	%	20...30
Air			Dust-free
			Oil-free
Required compressed air hose			4 × 0.75 (not included in scope of delivery)

Fig. 11-3: Technical data for IndraDyn S sealing air connection

Use the SUP-M01-MSK accessory kit for motors with encoder connection RGS1000 and the SUP-M02-MSK accessory kit for motors with power connection RLS1300.



Proper functioning of the sealing air application requires a proper sealing function of the radial shaft sealing ring. Please observe the information about maintenance intervals ([Fig.: 8.2](#)).

Assembly

⚠ WARNING

Danger! Electric voltage! Operations in the vicinity of live parts are extremely dangerous.



Work required on the electric system may only be carried out by skilled electricians. Tools for electricians (VDE tools) are absolutely necessary.

Prior to commencing work:

1. Isolate.
2. Protect the system or plant against restart.
3. Ensure de-energization.
4. Ground and short-circuit.
5. Cover or shield any adjacent live parts.

⚠ WARNING

Electrocution by live parts of more than 50V!



- ▶ Open connectors of the motor only when the system has been de-energized.

- ▶ Mount SUP-M01-MSK to encoder flange socket RGS1000 ([Fig.: 11-4](#) and SUP-M02-MSK to power flange socket RLS1300 ([Fig.: 11-5](#))).
- ▶ Loosen the screws of the encoder plug cover and remove the cover.
- ▶ Mount the sealing air connection
- ▶ Screw the encoder plug cover with the air-pressure connector kit to the motor. Tightening torque of the screws RGS1000 1.3 Nm, RLS1300 3.1 Nm. Use screwlock (e.g., Loctite 243®)

Extension and Modification

- ▶ Connect the quick-action pneumatic coupling of the accessory kit to the regulated compressed air source.




Fig. 11-4: Mounting SUP-M01-MSK to RGS1000




Fig. 11-5: Mounting SUP-M02-MSK to RLS1300

12 Troubleshooting

12.1 Troubleshooting Procedure

As a matter of principle, the instructions in the project planning and commissioning manuals must be followed in case of failures and errors. If necessary, the manufacturer must be contacted.

Malfunction	Failure cause	Measures
The motor does not run	Drive enable is missing	Activate the drive enable
	Controller fault	Troubleshooting according to the documentation of the controller
	Supply voltage is missing	Check the supply voltage
	Brake is not released	Check the brake activation
Vibrations	Coupling elements or attachments are poorly balanced	Re-balance
	Adjustment of shaft end attachments (coupling, gearbox, ...) is insufficient	Re-align the attachments
	Mounting screws are loose	Lock the screw connections as specified
Running noise	Foreign bodies within the motor	Stop operation of the motor -> repair by manufacturer
	Bearing is damaged	Stop operation of the motor -> repair by manufacturer
High motor temperature Motor temperature monitoring unit responds	Operation outside of characteristic data	Reduce the load, check the sizing if necessary
	Heat dissipation is impaired	Clean the motor Clean the grille of the fan unit and check the function of the fan Check the coolant circuit of liquid cooling systems
Wrong or incorrect temperature displayed	Temperature sensor not connected	Connect the temperature sensor
	Temperature sensor is defective	Stop operation of the motor -> repair by manufacturer Connect the backup temperature sensor, if any is available.

Fig. 12-1: Measures to be taken in case of MSK motor failures

13 Technical Data

Technical data with operating characteristic curves are described in the project planning manual for all motor types. Please, refer to the following documentation for relevant information.

	Title	Document type	Document number
	Rexroth IndraDyn S - Synchronous Motors MSK	Project Manual Planning	DOK-MOTOR*-MSK*****-PR---P
	Rexroth Indra Dyn S Synchronous Motors MSK for Hazardous Areas	Project Manual Planning	DOK-MOTOR*-MSK*EXGIIK3-PR---P

Fig. 13-1: Additional documentation

14 Appendix

Appendix

14.1 Declarations of Conformity

Electric Drives
and Controls

Hydraulics

Linear Motion and
Assembly Technologies

Pneumatics

Service

Rexroth
Bosch Group**Konformitätserklärung**Dok.-Nr.: TC30318-1
Datum: 2012-02-01

- nach Maschinenrichtlinie 2006/42/EG
- nach Niederspannungsrichtlinie 2006/95/EG
- nach EMV-Richtlinie 2004/108/EG
- nach Druckgeräte-Richtlinie 97/23/EG
- nach ATEX-Richtlinie 94/9/EG

Hiermit erklärt der Hersteller,

Bosch Rexroth Electric Drives and Controls GmbH
Bürgermeister-Dr.-Nebel-Straße 2
97816 Lohr a. Main / Germany

dass das nachstehende Produkt

Bezeichnung: AC-Motor
Typ: MSK030, MSK040, MSK043, MSK050, MSK060, MSK061, MSK070, MSK071, MSK075, MSK076, MSK100, MSK101, MSK103, MSK131, MSK133

Ab Herstellendatum: 2009-01-08

in Übereinstimmung mit der oben genannten EU-Richtlinie entwickelt, konstruiert und gefertigt wurde.

Angewandte harmonisierte Normen:

Norm	Titel	Ausgabe
EN 60034-1	Drehende elektrische Maschinen – Teil 1: Bemessung und Betriebsverhalten	2010+ Cor.:2010
EN 60034-5	Drehende elektrische Maschinen – Teil 5: Schutzarten aufgrund der Gesamtkonstruktion von drehenden elektrischen Maschinen (IP-Code) – Einteilung	2001 + A1:2007

Weitere Erläuterungen:

Dieses Produkt ist eine Einbaukomponente, die aufgrund ihrer Einbaueigenschaften nicht vornehmlich den Vorschriften für Endgeräte, Maschinen oder Anlagen entsprechen kann. Es darf daher nur zu Einbauzwecken verwendet werden. Die Bewertung der elektrischen und mechanischen Sicherheit, der Umwelteinflüsse (Fremdkörper, Feuchtigkeit) muss im eingebauten Zustand am Endprodukt erfolgen.

Im eingebauten Zustand können sich die EMV-Eigenschaften dieses Produktes ändern.

Deshalb ist für das Endprodukt (Endgerät, Maschine, Anlagen) eine Überprüfung der EMV-Eigenschaften durch den Endprodukthersteller zweckmäßig.

Lohr a. Main , den 2012-02-01 ppa.

Joachim Hennig
Werkleitung LoP2

i.V.

Eberhard Schemm
Entwicklungsbereichsleiter Antriebe

Änderungen im Inhalt der Konformitätserklärung sind vorbehalten. Derzeit gültige Ausgabe auf Anfrage.

Fig. 14-1: CE conformity MSK

Declaration of Conformity		Doc. No.:	TC30318-1		
		Date:	2012-02-01		
<input type="checkbox"/>	in accordance with Machinery Directive 2006/42/EC				
<input checked="" type="checkbox"/>	in accordance with Low Voltage Directive 2006/95/EC				
<input type="checkbox"/>	in accordance with EMC Directive 2004/108/EC				
<input type="checkbox"/>	in accordance with Pressure Equipment Directive 97/23/EC				
<input type="checkbox"/>	in accordance with ATEX Directive 94/9/EC				
The manufacturer					
Bosch Rexroth Electric Drives and Controls GmbH Buergermeister-Dr.-Nebel-Strasse 2 97816 Lohr am Main / Germany					
hereby declares that the product below					
Name:	AC motor				
Type	MSK030, MSK040, MSK043, MSK050, MSK060, MSK061, MSK070, MSK071, MSK075, MSK076, MSK100, MSK101, MSK103, MSK131, MSK133				
from production date	2009-01-08				
was developed, designed and manufactured in compliance with the above-mentioned EU directive.					
Harmonized standards applied:					
Standard	Title	Edition			
EN 60034-1	Rotating electrical machines - Part 1: Rating and performance	2010+ Cor.: 2010			
EN 60034-5	Rotating electrical machines - Part 5: Degrees of protection provided by integral design of rotating electrical machines (IP-Code) - Classification	2001+A1:2007			
Further explanations:					
This product is a mounting component which mounting characteristics cannot be with subject to the directives for end devices, machines or installation from the beginning. It should only be used for installation applications. The evaluation of electrical and mechanical safety and environmental influences (foreign bodies, humidity) must be done in mounted condition at the end product.					
The evaluation of electrical and mechanical safety and environmental influences (foreign bodies, humidity) must be done in mounted condition at the end product.					
In the assembled state, the EMC properties of the product may change. Therefore, an inspection of the EMC characteristics via the end product manufacturer is advisable for the end product (end device, machine or installation).					
Place/Date/Signature as in the original declaration of conformity.					
We reserve the right to make changes to the content of the Declaration of Conformity. Current issue on request.					

Fig. 14-2: Declaration of Conformity TC30318-1:2012-02-01 (copy/translation)


Appendix

14.2 Terminal Box**14.2.1 General**

Motor	Terminal box
MSK101X-----F--NPNN; (X=C,D,E,F)	RZK3100
MSK131X-----E--NPNN; (X=F)	RKL1300
MSK133X-----E--NP35; (X=B)	RKL1200
MSK133X-----E--NP35; (X=C,D,E)	RKL1300


When using terminal boxes, observe the following:

- Use ready-made cables of Rexroth, see documentation DOK-CONNEX-CABLE*INDRV-AU----P, "Rexroth Connection Cables IndraDrive and IndraDyn".
- Observe the circuit diagrams specified in the Project Planning Manual, see DOK-MOTOR*-MSK*****-PR----P, "Rexroth IndraDyn S Synchronous Motors MSK".
- The connections must be established such that a permanent safe electrical connection is ensured.
- Establish a safe protective conductor connection.
- Use the related cable ends for terminal boxes (no protruding wire ends).
- Only use terminal boxes which are free from dirt, foreign bodies and humidity.
- Close cable entry openings that are not required and the box itself such that they are tight to dust and water.

14.2.2 Terminal Box Type RZK3100


- | | |
|---|---------------------------------------|
| ① | 4 screws; M _A 5.9...7.1 Nm |
| ② | Cover |
| ③ | Seal |
| ④ | Closure M32 (power) |
| ⑤ | Closure M20 (encoder) |

Fig. 14-3: Terminal box RZK3100



- ① Screwed connection M20 x 1.5, plastic (encoder)
 ② Screwed connection M32 x 1.5, plastic (power cable 2.5 ... 10.0 mm²)
 ③ Screwed connection M40 x 1.5, plastic (power cable 16.0 mm²)
 ④ M32 / M40 extension, plastic (power cable 16.0 mm²)

Fig. 14-4: Selecting screw unions



- ① Encoder cable shield connection
 ② 8-pin clamp terminal, encoder
 ③ 2-pin clamp terminal, brake/temperature
 ④ Power connection U,V,W (max. 16.0 mm²)
 ⑤ M4x10 power cable shield connection
 ⑥ M8x12 power cable protective conductor connection


Fig. 14-5: Connection points of power and encoder cables

Connection diagram




The following connection diagram shows a possible connection. The installation regulations applicable at the place of machine installation must be complied with.

Appendix



- ① Motor housing
 - ② Terminal box
 - ③ Equipotential bonding connection at the motor (only available on ATEX motors)
 - ④ Equipotential bonding connection at the machine (necessary for ATEX motors)
 - ⑤ Rexroth drive controller
- Fig. 14-6: Connection Scheme Terminal Boxes RZK3100*

14.2.3 Terminal Boxes Type RKL1200, RKL1300



- | | |
|-----|--|
| ① ⑤ | Screwed connection |
| ② | O-ring |
| ③ | Adapter plate for receiving the screwed connection |
| ④ | Reduction (optional for cable cross-sections of 1.5, 2.5 mm ²) |
| ⑥ | Adapter plate mounting screws |
| ⑦ | Cover screws |
| ⑧ | Cover |
| ⑨ | Seal of terminal box cover |

Fig. 14-7: Assembly RKL1200, RKL1300

Power connection is implemented with a single cable or two cables. The ready-made power cables are introduced into the terminal box via adapter plates (2 × M40×1.5) and cable glands.

Power cable connection at terminal box

The following steps must be taken to connect the power cable to the terminal box:

1. Open the cover of the terminal box.
Unscrew and remove the mounting screws (4 pcs.).
2. Remove the protection cover of cable gland.
3. Detach the adapter plate ③ from the terminal box.
4. Firmly secure the adapter plate to the metric cable gland on the power cable. Use a reduction piece for power wire cross-sections of 1.5 mm² and 2.5 mm².
Before attaching the power cable to the adapter plate, check the O-ring for proper condition and correct position.
5. Place the power cable through the opening into the terminal box up to the adapter plate. Attach the adapter plate to the terminal box.
Tightening torque of the screws ⑥: 9 Nm (±10%)

Appendix

Before attaching the adapter plate ⑥ to the terminal box, check the O-ring ⑤ inserted in the adapter plate for proper condition and correct position.

6. Connect the wires according to the standard or double cabling connection diagram.

Observe the following tightening torques:

Designation	Type	Connection: mm ²	Size / type	Tightening torque M _A Nm
U-V-W	AEH	1,5 ... 35	M6	2,5
1 ... 6 (Temp / brake)	AEH	0,2 ... 2,5	Tension spring clamp	-
PE	RKS		M8	3,8

WEF = wire end ferrule

RTE = ring terminal end


Fig. 14-8: Tightening torque for screws in Nm within the terminal boxes

7. Close and attach the terminal box lid.

Apply Loctite 243 (liquid screwlock) to the thread of the mounting screws for the lid ① and then attach the lid with all of the mounting screws.

Screw tightening torque: 6.5 Nm ($\pm 10\%$)

Before attaching the cover to the terminal box, check the glued-in seal ② on the terminal box cover for proper condition and correct position.



① Terminal strip (brake, temperature sensor)


② Ground terminal connection

U V W Power connection

Fig. 14-9: Connection points

Connection scheme single cabling

The following connection diagram shows a possible connection. The installation regulations applicable at the place of machine installation must be complied with.



- ① Motor housing
- ② Terminal box
- ③ Holding Brake (Optional)
- ④ Equipotential bonding connection at the motor (only available on ATEX motors)
- ⑤ Equipotential bonding connection at the machine (necessary for ATEX motors)
- ⑥ Rexroth drive controller

Fig. 14-10: Connection scheme terminal box single cabling RLK1200, RKL1300


Double cabling connection diagram

Motor connection with two power cables is required if a corresponding single cable cannot be used due to the bending radius or due to its dimensions.



The following connection diagram shows a possible connection. The installation regulations applicable at the place of machine installation must be complied with.

Appendix



- ① Motor housing
 ② Terminal box
 ③ Holding Brake (Optional)
 ④ Equipotential bonding connection at the motor (only available on ATEX motors)
 ⑤ Equipotential bonding connection at the machine (necessary for ATEX motors)
 ⑥ Rexroth drive controller

Fig. 14-11: Connection scheme terminal box double cabling RLK1200, RKL1300



- Fuses F1 (NH...) protecting the wires against overload in case of a cable break must be dimensioned according to the current carrying capacity of the particular line cross-section.
- The fuses should be installed in the control cabinet such that they are as close as possible to the power output of the controller.
- The shield of the motor power cable must be connected to the control cabinet on the motor side of the fuses such that it is conducting over a large area.
- Power cables are not available to establish the double cabling. To install the fuses, standard Rexroth power cables must be opened and cut to the appropriate length on site.

Index

A

Accessories.....	55
Accumulators.....	53
Alignment.....	23
Ambient temperature.....	23
Assembly	
Foot assembly	33

B

Balance.....	35
Balancing.....	23
Batteries.....	53
bearing service life.....	25

C

CE.....	64
Centering hole.....	25
Concentricity	23
Connection cables.....	47
Connection scheme terminal box double cabling.....	72
Connection scheme terminal boxes MSK101.....	68
Connection scheme terminal box single cabling. 71	
Contained substances	
see "Significant components"	53
Cooling.....	25
Cooling fins.....	47
Cooling water.....	42
Coupling.....	35

D

Degree of protection.....	23, 24
Design.....	24
Disposal.....	53
Drag chains.....	48

E

Electrical connection.....	23
Encoder system.....	23
Energy management chains.....	48
Exchanging the motor.....	51

F

Flange.....	23
Flange socket.....	36
Flange socket connection diagram.....	38

H

Hazardous substances.....	53
Heat dissipation.....	47

I

Installation altitude	23
Installation space.....	26
Insulation class.....	23

K

Key.....	25
----------	----

L

Lifting eye bolts.....	29
Liquid cooling.....	26, 42
Coolant inlet	42
Coolant outlet	42
Coolant port thread	42

M

Minimum distance	
Fan	26
Motor	25
Motor design.....	23
Motor holding brake.....	23
Mounting screws.....	33

N

Natural convection.....	25
-------------------------	----

P

Packaging.....	53
Permanent magnets.....	53
Plug connector for 1-phase fan connection.....	41
Plug connector for 3-phase fan connection.....	41
Plug connectors.....	36
Pole pattern.....	39
Production processes.....	53
Pulley.....	35
Pulling off the transmission element.....	51

R

Radial forces.....	34
Recycling.....	54
Return of products.....	53
Run-out.....	23

S

Sealing air.....	56
Service.....	49
Shaft end.....	23
Significant components.....	53
Sound pressure level.....	23
Storage.....	30
Storage time.....	30

Index

S	
Surface ventilation.....	25
T	
Terminal box.....	66
Terminal box for 1-phase fan connection.....	42
Transmission element.....	35
Fitting	35
Pulling off	51
Transport.....	29
Troubleshooting.....	59
Turning torque.....	40
Type code.....	27
T	
Types of installation.....	24
U	
UL listing.....	23
V	
Vibration severity grade.....	23
W	
Water cooling	
see Liquid Cooling	26

Notes

Rexroth
Bosch Group

Bosch Rexroth AG
Electric Drives and Controls
P.O. Box 13 57
97803 Lohr, Germany
Bgm.-Dr.-Nebel-Str. 2
97816 Lohr, Germany
Tel. +49 9352 18 0
Fax +49 9352 18 8400
www.boschrexroth.com/electrics



R911325169

DOK-MOTOR*-MSK*****-IT02-EN-P